



ACURA MANUFACTURER-SPECIFIC TROUBLE CODES

Compiled by ***OBDCodeX***



www.obdcodex.com

Codes	Definition
Acura B1000	Communication Bus Line Error
Acura B1001	Multiplex Integrated Control Unit (MICU) Internal Error
Acura B1002	Multiplex Integrated Control Unit (MICU) Internal Error
Acura B1005	MICU Lost Communication with Relay Control Module (RM Message)
Acura B1007	MICU Lost Communication with Combination Switch Control Unit (HLSW Message)
Acura B1008	MICU Lost Communication With Gauge Control Module (A/T Message)
Acura B1011	MICU Lost Communication with Gauge Control Module (VSP/NE Message)
Acura B1012	MICU Lost Communication with Rear MICU (RJC Message)
Acura B1013	MICU Lost Communication with Driver's MPCS Unit (ASLOCKSW Message)
Acura B1014	MICU Lost Communication With Driver's MPCS Unit (DOORSW Message)
Acura B1015	MICU Lost Communication with Driver's MPCS Unit (DRLOCKSW Message)
Acura B1016	MICU Lost Communication With Keyless Access Control Unit (PANIC Message)
Acura B1032	MICU Lost Communication with the SRS Unit (CDS Message)
Acura B1050	Communication Bus Line Error
Acura B1051	Relay Control Module Internal (CPU) Error
Acura B1052	Relay Control Module Internal (EEPROM) Error
Acura B1055	Relay Control Module Lost Communication with MICU (MICU Message)
Acura B1056	Relay Control Module Lost Communication with MICU (ALARM Message)
Acura B1057	Relay Control Module Lost Communication with MICU (DOORSW Message)
Acura B1060	Relay Control Module Lost Communication with Gauge Control Module (VPS/NE Message)
Acura B1061	Relay Control Module Lost Communication with Gauge Control Module (A/T Message)
Acura B1062	Relay Control Module Lost Communication with Combination Switch Control Unit (HLSW Message)
Acura B1063	Relay Control Module Lost Communication with Combination Switch Control Unit (WIPSW Message)
Acura B1064	Relay Control Module Lost Communication With Driver's MPCS Unit (DOORSW Message)
Acura B1065	Relay Control Module Lost Communication with Driver's MPCS Unit (DRLOCKSW Message)
Acura B1066	Relay Control Module Lost Communication With Keyless Access Control Unit (PANIC Message)
Acura B1075	Headlight Switch Back-up Circuit Malfunction
Acura B1076	Windshield Wiper Switch Back-up Circuit Malfunction
Acura B1077	Windshield Wiper Auto Switch Circuit Malfunction

Codes	Definition
Acura B1078	Daytime Running Lights System Error
Acura B1079	Daytime Running Lights Malfunction
Acura B1080	Power Supply Circuit (IG1 Line) Input Error for Relay Control Module and MICU
Acura B1132	Left Rear Power Window Motor Pulse A Error
Acura B1133	Left Rear Power Window Motor Pulse B Error
Acura B1134	Right Rear Power Window Motor Pulse A Error
Acura B1135	Right Rear Power Window Motor Pulse B Error
Acura B1136	Right Rear Power Window Switch Internal Error
Acura B1147	Left Rear Power Window Position Information Error
Acura B1148	Left Rear Power Window Switch Internal Error
Acura B1149	Right Rear Power Window Position Information Error
Acura B1150	Communication Bus Line Error
Acura B1152	Gauge Control Module Internal (EEPROM) Error
Acura B1155	Gauge Control Module Lost Communication with Combination Switch Control Unit (HLSW Message)
Acura B1156	Gauge Control Module Lost Communication with Combination Switch Control Unit (WIPSW Message)
Acura B1157	Gauge Control Module Lost Communication with MICU (MICU Message)
Acura B1158	Gauge Control Module Lost Communication with Relay Control Module (RM Message)
Acura B1159	Gauge Control Module Lost Communication with MICU (DOORSW Message)
Acura B1161	Gauge Control Module Lost Communication With Keyless Access Control Unit (REMOTE ID Message)
Acura B1162	Gauge Control Module Lost Communication with Power Tailgate (PTG Message)
Acura B1166	Gauge Control Module Lost Communication With Adaptive Front Lighting Control Unit (AFS Message)
Acura B1168	Gauge Control Module Lost Communication with PCM (ENG Message)
Acura B1169	Gauge Control Module Lost Communication with the PCM (A/T Message)
Acura B1170	Gauge Control Module Lost Communication with the VSA Modulator-Control Unit (VSA Message)
Acura B1171	Gauge Control Module Lost Communication With Adaptive Cruise Control Unit (ACC Message)
Acura B1173	Gauge Control Module Lost Communication with the TPMS Control Unit (TPMS Message)
Acura B1175	Fuel Level Sensor (Fuel Gauge Sending Unit) Circuit Open
Acura B1176	Fuel Level Sensor (Fuel Gauge Sending Unit) Circuit Short
Acura B1177	Battery Voltage Abnormal
Acura B1178	F-CAN Communication Line Error
Acura B1180	Gauge Control Module Lost Communication with MICU (AUTOLT Message)

Codes	Definition
Acura B1181	Gauge Control Module Lost Communication With Driver's MPCU Unit (DOORSW Message)
Acura B1182	Gauge Control Module Lost Communication with Driver's MPCU Unit (DRLOCKSW Message)
Acura B1187	Gauge Control Module Lost Communication with SRS Unit (SRS Message)
Acura B1188	Gauge Control Module Lost Communication with the MICU (RM Message)
Acura B1189	Gauge Control Module Lost Communication with Active Damper System Control Unit (ADS Message)
Acura B1200	Communication Bus Line Error
Acura B1202	Climate Control Unit Internal Error
Acura B1205	Climate Control Unit Lost Communication with Gauge Control Module (VSP/NE message)
Acura B1206	Climate Control Unit Lost Communication with Gauge Control Module (ECT message)
Acura B1207	Climate Control Unit Lost Communication with Gauge Control Module (ILLUMI message)
Acura B1208	Climate Control Unit Lost Communication with Keyless Access Control Unit (FOB ID message)
Acura B1213	An Open in the Rear Evaporator Temperature Sensor Circuit
Acura B1214	Short in the Rear Evaporator Temperature Sensor Circuit
Acura B1215	Open or Short in the Recirculation Control Motor Circuit
Acura B1223	Problem in the Rear Blower Motor Circuit
Acura B1225	Open in the In-car Temperature Sensor Circuit
Acura B1226	Short in the In-car Temperature Sensor Circuit
Acura B1227	Open in the Outside Air Temperature Sensor Circuit
Acura B1228	Short in the Outside Air Temperature Sensor Circuit
Acura B1229	Open in the Sunlight Sensor Circuit
Acura B1230	Short in the Sunlight Sensor Circuit
Acura B1231	Open in the Front Evaporator Temperature Sensor Circuit
Acura B1232	Short in the Front Evaporator Temperature Sensor Circuit
Acura B1233	Open in the Driver's Air Mix Control Motor Circuit
Acura B1234	Short in the Driver's Air Mix Control Motor Circuit
Acura B1235	Problem in the Driver's Air Mix Control Linkage, Door, or Motor Circuit
Acura B1236	Open in the Passenger's Air Mix Control Motor Circuit
Acura B1237	Short in the Passenger's Air Mix Control Motor Circuit
Acura B1238	A Problem in the Passenger's Air Mix Control Linkage, Door, or Motor
Acura B1239	Open or Short in the Front Mode Control Motor Circuit
Acura B1240	Problem in the Front Mode Control Linkage, Doors, or Motor Circuit
Acura B1241	Problem in the Front Blower Motor Circuit
Acura B1244	Open in the Rear Air Mix Control Motor Circuit
Acura B1245	Short in the Rear Air Mix Control Motor Circuit
Acura B1246	Problem in the Rear Air Mix Control Linkage, Door, or Motor Circuit

Codes	Definition
Acura B1250	Communication Bus Line Error
Acura B1252	Combination Switch Control Unit Internal (EEPROM) Error
Acura B1255	Combination Switch Control Unit Lost Communication with MICU (MICU Message)
Acura B1275	Combination Light Switch OFF Position Circuit Malfunction
Acura B1276	Combination Light Switch Parking (SMALL) Position Circuit Malfunction
Acura B1277	Headlight Switch AUTO Position Circuit Malfunction
Acura B1278	Headlight Switch ON Position Circuit Malfunction
Acura B1279	Headlight Switch DIMMER Position Circuit Malfunction
Acura B1280	Turn Signal Switch Circuit Malfunction
Acura B1281	Windshield Wiper Switch MIST Position Circuit Malfunction
Acura B1282	Windshield Wiper Switch INT (AUTO) Position Circuit Malfunction
Acura B1283	Windshield Wiper Switch LOW Position Circuit Malfunction
Acura B1284	Windshield Wiper Switch HIGH Position Circuit Malfunction
Acura B1350	Communication Bus Line Error
Acura B1352	Power Tailgate Control Unit Internal (EEPROM) Error
Acura B1355	Power Tailgate Control Unit Lost Communication with MICU (MICU Message)
Acura B1356	Power Tailgate Control Unit Lost Communication with Driver's MPCU Unit (DRLOCKSW Message)
Acura B1357	Power Tailgate Control Unit Lost Communication with Gauge Control Module (VSP/NE Message)
Acura B1358	Power Tailgate Control Unit Lost Communication with Driver's MPCU Unit (ASLOCKSW Message)
Acura B1359	Power Tailgate Control Unit Lost Communication with Gauge Control Module (A/T Message)
Acura B1375	Driver's Door Power Tailgate Switch Circuit Malfunction
Acura B1376	Tailgate Outer Handle Switch Circuit Malfunction
Acura B1377	Inside Tailgate Switch Circuit Malfunction
Acura B1378	Power Tailgate Right Pinch Sensor Circuit Malfunction
Acura B1379	Power Tailgate Left Pinch Sensor Circuit Malfunction
Acura B1380	Power Tailgate Closer Unit Neutral Switch Circuit Malfunction
Acura B1381	Power Tailgate Closer Unit Release Switch Circuit Malfunction
Acura B1382	Power Tailgate Closer Unit Full Latch Switch Circuit Malfunction
Acura B1383	Power Tailgate Closer Unit Ratchet Switch Circuit Malfunction
Acura B1384	Power Tailgate Closer Unit Half Latch Switch Circuit Malfunction
Acura B1386	Power Tailgate Sensor Pulse A Circuit Malfunction
Acura B1387	Power Tailgate Sensor Pulse B Circuit Malfunction
Acura B1388	Power Tailgate Motor Circuit Malfunction
Acura B1389	Power Tailgate Motor Clutch Circuit Malfunction
Acura B1390	Power Tailgate Closer Function Error
Acura B1575	Automatic Lighting Sensor Circuit Malfunction
Acura B1600	Communication Bus Line Error

Codes	Definition
Acura B1605	Keyless Access Control Unit Lost Communication With MICU (MICU Message)
Acura B1750	Communication Bus Line Error
Acura B1775	Microphone Input/Output Short to Power/Open
Acura B1776	Microphone Input/Output Short to Ground/Open
Acura B1779	HFL Switch (HFL TALK/HFL BACK Buttons) Circuit Open/Short
Acura B1780	HFL Switch (HFL TALK/HFL BACK Buttons) Circuit Short
Acura B1785	Incorrect Configuration (VEHINFO Frame)
Acura B1786	HandsFreeLink Control Unit Lost Communication with Gauge Control Module (VEHINFO Frame)
Acura B1792	HandsFreeLink Control Unit Internal Error
Acura B1800	Communication Bus Line Error
Acura B1802	Power Seat Control Unit Internal (EEPROM) Error
Acura B1805	Power Seat Control Unit Lost Communication with Gauge Control Module (VSP/NE Message)
Acura B1806	Power Seat Control Unit Lost Communication with MICU (MICU Message)
Acura B1808	Power Seat Control Unit Lost Communication with Gauge Control Module (A/T Message)
Acura B1810	Power Seat Control Unit Lost Communication with MICU (MIRRORSW Message)
Acura B1811	Power Seat Control Unit Lost Communication with MICU (DOORSW Message)
Acura B1812	Power Seat Control Unit Lost Communication with Driver's MPCU Unit (MEMSW Message)
Acura B1825	Power Seat Slide Motor Pulse Error
Acura B1826	Power Seat Front Up-down Motor Pulse Error
Acura B1827	Power Seat Rear Up-down Motor Pulse Error
Acura B1828	Power Seat Recline Motor Pulse Error
Acura B1829	A/T P Signal and VSS Signal Mismatch
Acura B1835	Power Tilt/Telescopic Steering Switch Signal Input Error
Acura B1836	Power Seat Position Sensor Circuit Short
Acura B1837	Driving Position Memory Recall Timeout
Acura B1840	Tilt Motor Pulse Error
Acura B1841	Telescopic Motor Pulse Error
Acura B1842	Power Tilt/Telescopic Position Sensor Power Supply Circuit (SVCC Line) Short
Acura B1843	Power Seat Control Unit Lost Communication with Power Tilt/Telescopic Steering Control Unit (UART line)
Acura B1844	Power Seat Slide Switch Circuit Malfunction
Acura B1845	Power Seat Recline Switch Circuit Malfunction
Acura B1846	Power Seat Front Up-Down Switch Circuit Malfunction
Acura B1847	Power Seat Rear Up-Down Switch Circuit Malfunction
Acura B1900	Communication Bus Line Error
Acura B1905	Immobilizer-Keyless Control Unit Lost Communication with Driver's MPCU Unit (DRLOCKSW Message)

Codes	Definition
Acura B1906	Immobilizer-Keyless Control Unit Lost Communication with Gauge Control Module (A/T Message)
Acura B1950	Communication Bus Line Error
Acura B1955	Rear MICU Lost Communication with MICU (MICU Message)
Acura B1956	Rear MICU Lost Communication with Gauge Control Module (A/T Message)
Acura B1957	Rear MICU Lost Communication with Combination Switch Control Unit (HLSW Message)
Acura B1958	Rear MICU Lost Communication with Combination Switch Control Unit (WIPSW Message)
Acura B1959	Rear MICU Lost Communication with Relay Control Module (RM Message)
Acura B2100	Communication Bus Line Error
Acura B2150	Communication Bus Line Error
Acura B2152	Driver's MPCS Unit Internal (EEPROM) Error
Acura B2155	Driver's MPCS Unit Lost Communication with MICU (MICU Message)
Acura B2156	Driver's MPCS Unit Lost Communication with MICU (MIRRORSW Message)
Acura B2157	Driver's MPCS Unit Lost Communication with Gauge Control Module (ILLUMI Message)
Acura B2160	Driver's MPCS Unit Lost Communication with Gauge Control Module (VSP/NE Message)
Acura B2161	Driver's MPCS Unit Lost Communication with MICU (DOORSW Message)
Acura B2162	Driver's MPCS Unit Lost Communication with Relay Control Module (RM Message)
Acura B2175	Driver's Power Window Motor Pulse A Error
Acura B2176	Driver's Power Window Motor Pulse B Error
Acura B2177	Front Passenger's Power Window Motor Pulse A Error
Acura B2178	Front Passenger's Power Window Motor Pulse B Error
Acura B2179	Driver's Door Key Cylinder Switch LOCK/UNLOCK Signal Error
Acura B2180	Driver's Door Lock Switch LOCK/UNLOCK Signal Error
Acura B2181	Driver's Door Lock Knob Switch LOCK/UNLOCK Signal Error
Acura B2182	Left Power Mirror Horizontal Sensor Signal Error
Acura B2183	Left Power Mirror Vertical Sensor Signal Error
Acura B2184	Right Power Mirror Horizontal Sensor Signal Error
Acura B2185	Right Power Mirror Vertical Sensor Signal Error
Acura B2186	Front Passenger's Door Lock Switch LOCK/UNLOCK Signal Error
Acura B2187	Communication Line (UART Line) Driver's MPCS Unit cannot send UART messages.
Acura B2188	Communication Line (UART Line) Driver's MPCS Unit cannot receive UART messages from Front Passenger's MPCS Unit.
Acura B2189	Driver's Power Window Position Detect Circuit Error
Acura B2190	Front Passenger's Power Window Position Detect Circuit Error
Acura B2191	Front Passenger's MPCS Unit Internal (EEPROM) Error
Acura B2200	Communication Bus Line Error

Codes	Definition
Acura B2202	AcuraLink Control Unit EEPROM Error
Acura B2204	B-CAN Communication Line Error
Acura B2205	F-CAN Communication Line Error
Acura B2206	SRS Unit Lost Communication with AcuraLink Control Unit (XM receiver)
Acura B2207	Navigation Unit Lost Communication with AcuraLink Control Unit
Acura B2208	HandsFreeLink Control Unit Lost Communication with AcuraLink Control Unit
Acura B2209	AcuraLink Control Unit Internal Error
Acura B2211	F-CAN Communication Line Error with PCM
Acura B2212	Gauge Control Module Lost F-CAN Communication Line Error with AcuraLink Control Unit (XM receiver)
Acura B2240	XM Antenna Error
Acura B2248	HIP Power Supply Abnormal (more than 16 V)
Acura B2249	HIP Power Supply Abnormal (less than 9 V)
Acura B2965	Climate Control Unit Lost Communication with Rear Climate Control Panel
Acura B2967	Open in the Humidity Sensor Circuit (WINDSHIELD DEFROST)
Acura B2968	Short in the Humidity Sensor Circuit (WINDSHIELD DEFROST)
Acura B2969	Climate Control Unit Lost Communication with Combination Switch Control Unit (WIPSW message)
Acura B2970	Climate Control Unit Lost Communication with Relay Control Module (RM message)
Acura B2975	Open in the Driver's Vent Air Temperature Sensor Circuit
Acura B2976	Short in the Driver's Vent Air Temperature Sensor Circuit
Acura B2977	Open in the Passenger's Vent Air Temperature Sensor Circuit
Acura B2978	Short in the Passenger's Vent Air Temperature Sensor Circuit
Acura B2979	Open in the A/C Pressure Sensor Circuit
Acura B2980	Short in the A/C Pressure Sensor Circuit (WINDSHIELD DEFROST)
Acura B2981	Climate Control Unit Lost Communication with Navigation Unit
Acura B2982	Climate Control Unit Lost Communication with Each Control Motor
Acura B2983	Problem in the Recirculation Control Linkage, Door, or Motor Circuit
Acura B2984	Problem in the Driver's Cool Vent Control Linkage, Door, or Motor
Acura B2985	Problem in the Passenger's Cool Vent Control Linkage, Door, or Motor
Acura B2987	Problem in the Rear Vent Control Linkage, Door, or Motor
Acura B2991	Climate Control Unit Lost Communication with Audio Unit
Acura P1077	Intake Manifold Tuning (IMT) Valve Stuck in High RPM Position
Acura P1078	Intake Manifold Tuning (IMT) Valve Stuck in Low RPM Position
Acura P1102	Mass Airflow Sensor Signal Lower Than Expected
Acura P1103	Mass Airflow Sensor Signal Higher Than Expected
Acura P1106	MAP Sensor Circuit High Input (Intermittent)
Acura P1107	BARO Pressure Sensor Circuit Low Input
Acura P1108	BARO Pressure Sensor Circuit High Input
Acura P1109	Barometric Pressure (BARO) Sensor Circuit Out of Range High

Codes	Definition
Acura P1111	IAT Sensor Circuit High Input (Intermittent)
Acura P1112	IAT Sensor Circuit Low Input (Intermittent)
Acura P1114	ECT Sensor Circuit Low Input (Intermittent)
Acura P1115	ECT Sensor Circuit High Input (Intermittent)
Acura P1116	Engine Coolant Temperature (ECT) Sensor 1 Circuit Range/Performance Problem
Acura P1121	Throttle Position Sensor Intermittent High Input
Acura P1122	Throttle Position Sensor Intermittent Low Input
Acura P1128	Manifold Absolute Pressure (MAP) Sensor Signal Lower Than Expected
Acura P1129	Manifold Absolute Pressure (MAP) Sensor Signal Higher Than Expected
Acura P1133	HO2S-11 (Bank 1 Sensor 1) Insufficient Switching
Acura P1134	HO2S-11 (Bank 1 Sensor 1) Transition Time Ratio Error
Acura P1153	HO2S-21 (Bank 2 Sensor 1) Insufficient Switching
Acura P1154	HO2S-21 (Bank 2 Sensor 1) Transition Time Ratio
Acura P1162	Air Fuel Sensor (Bank 1 Sensor 1) Circuit Malfunction
Acura P1163	Air Fuel Sensor (Bank 1 Sensor 1) Slow Response
Acura P1164	Air Fuel Sensor (Bank 1 Sensor 1) Range/Performance
Acura P1166	Air Fuel Sensor (Bank 1 Sensor 1) Heater Circuit Malfunction
Acura P1167	Air Fuel Sensor (Bank 1 Sensor 1) Heater Circuit Malfunction
Acura P1171	Fuel System Lean During Acceleration Detected
Acura P1172	Rear Air/Fuel Ratio (A/F) Sensor (Bank 1, Sensor 1) Circuit Out of Range High
Acura P1174	Front Air/Fuel Ratio (A/F) Sensor (Bank 2, Sensor 1) Circuit Out of Range High
Acura P1201	Cylinder 1 Misfire Detected
Acura P1202	Cylinder 2 Misfire Detected
Acura P1203	Cylinder 3 Misfire Detected
Acura P1204	Cylinder 4 Misfire Detected
Acura P1205	Cylinder 5 Misfire Detected
Acura P1206	Cylinder 6 Misfire Detected
Acura P1241	Throttle Valve Control Motor 1 Circuit Malfunction
Acura P1242	Throttle Valve Control Motor 2 Circuit Malfunction
Acura P1243	Throttle Position Insufficient
Acura P1244	Insufficient Closed Throttle Position Detected
Acura P1246	Accelerator Position Sensor 1 Circuit Malfunction
Acura P1247	Accelerator Position Sensor 2 Circuit Malfunction
Acura P1248	Accelerator Pedal Position Sensor Correlation
Acura P1259	VTEC System Malfunction (Bank 1)
Acura P1279	VTEC System Malfunction (Bank 2)
Acura P1297	Electrical Load Detector (ELD) Circuit Low Voltage
Acura P1298	Electrical Load Detector (ELD) Circuit High Voltage
Acura P1300	Random Misfire Detected
Acura P1301	Cylinder 1 Misfire Detected

Codes	Definition
Acura P1302	Cylinder 2 Misfire Detected
Acura P1303	Cylinder 3 Misfire Detected
Acura P1304	Cylinder 4 Misfire Detected
Acura P1305	Cylinder 5 Misfire Detected
Acura P1306	Cylinder 6 Misfire Detected
Acura P1316	Spark Plug Detection Module Circuit Fault (Bank 2)
Acura P1317	Spark Plug Detection Module Circuit Fault (Bank 1)
Acura P1318	Spark Plug Detection Module Reset Circuit Fault (Bank 2)
Acura P1319	Spark Plug Detection Module Reset Circuit Fault (Bank 1)
Acura P1336	Crankshaft Position Sensor 'B' Circuit Malfunction
Acura P1337	Crankshaft Position Sensor 'B' Circuit No Signal
Acura P1359	CKP/TDC/CYP Sensor Circuit Malfunction
Acura P1361	Top Dead Center Sensor Intermittent Signal
Acura P1362	Top Dead Center 1 Sensor No Signal
Acura P1366	Top Dead Center Sensor 2 Circuit Intermittent Signal
Acura P1367	Top Dead Center Sensor 2 No Signal
Acura P1381	Camshaft Position Sensor 1 No Signal
Acura P1382	Camshaft Position Sensor 1 No Signal
Acura P1386	Camshaft Position Sensor 2 Circuit Malfunction
Acura P1387	Camshaft Position Sensor 2 No Signal
Acura P1404	EGR Valve Stuck Closed Malfunction
Acura P1441	EVAP Vacuum Switch Circuit High Input
Acura P1454	Fuel Tank Pressure (FTP) Sensor Circuit Range/Performance Problem
Acura P1456	EVAP System Leak Detected (Fuel Tank Area)
Acura P1457	EVAP System Leak Detected (Canister Area)
Acura P1459	EVAP Purge Flow Switch Circuit Malfunction
Acura P145C	Evaporative Emission (EVAP) System Purge Flow Malfunction
Acura P1486	Cooling System Malfunction
Acura P1491	EGR Valve Lift Sensor Insufficient Flow Detected
Acura P1498	EGR Valve Lift Sensor High Input
Acura P1508	Idle Air Control Valve Circuit Malfunction
Acura P1509	Idle Speed Control System High RPM
Acura P1519	Idle Air Control Valve Circuit Malfunction
Acura P1549	Charging System High Voltage
Acura P1607	PCM Internal Circuit 'A' Malfunction
Acura P1608	PCM Internal Circuit 'B' Malfunction
Acura P1618	Serial Peripheral Interface Communication
Acura P1625	PCM Unexpected Reset
Acura P1640	Output Driver Module 'A' Circuit Malfunction
Acura P1650	Output Driver Module Circuit Malfunction
Acura P1655	PCM Internal Circuit Malfunction
Acura P1656	PCM To VSA Unit Signal Line Circuit Malfunction
Acura P1658	Electronic Throttle Control System (ETCS) Control Relay ON Malfunction

Codes	Definition
Acura P1659	Electronic Throttle Control System (ETCS) Control Relay OFF Malfunction
Acura P1660	A/T (TCM) FI Data Line Circuit Malfunction
Acura P1671	A/T (TCM) FI Data Line No Signal
Acura P1672	A/T (TCM) FI Data Line Circuit Malfunction
Acura P1676	A/T (TCM) FI Data Line Circuit Malfunction
Acura P1677	A/T (TCM) FI Data Line Circuit Malfunction
Acura P1678	A/T (TCM) FPTDR Signal Line Circuit Malfunction
Acura P1683	Throttle Valve Default Position Spring Performance Problem
Acura P1684	Throttle Valve Return Spring Performance Problem
Acura P1690	A/T (TCM) TCSTB Data Line Circuit Malfunction
Acura P1696	TCFC Data Line Signal Low Input
Acura P1697	TUFT Data Line Signal High Input
Acura P16BB	Alternator B Terminal Circuit Low Voltage
Acura P16BC	Alternator FR Terminal Circuit/IGP Circuit Low Voltage
Acura P16BD	Starter Cut Relay 2 Malfunction
Acura P16BE	Starter Cut Relay 1 Malfunction
Acura P16BF	Starter Cut Relay STRLY Circuit Malfunction
Acura P16C0	PCM A/T Control System Incomplete Update
Acura P1705	A/T Transmission Range Switch Low Input
Acura P1706	A/T Transmission Range Switch Circuit No Gear Inputs
Acura P1709	A/T Transmission Gear Switch Circuit Malfunction
Acura P1710	A/T First Hold Switch Circuit Malfunction
Acura P1717	A/T Transmission Range Switch Circuit Malfunction
Acura P1738	A/T 2nd Pressure Switch Circuit Malfunction
Acura P1739	A/T 3rd Pressure Switch Circuit Malfunction
Acura P1740	A/T 4th Pressure Switch Circuit Malfunction
Acura P1743	Problem in Shift Control System; Shift Valve E Stuck OFF
Acura P1744	Problem in Shift Control System; Shift Valve E Stuck ON
Acura P1745	Problem in Shift Control System; Servo Control Valve Stuck OFF or Servo Valve Stuck OFF
Acura P1750	A/T Hydraulic Pressure Control Malfunction (Mechanical)
Acura P1751	A/T Hydraulic Pressure Control Malfunction (Mechanical)
Acura P1753	A/T Lockup Solenoid Valve 'A' Circuit Malfunction
Acura P1758	A/T Lockup Solenoid Valve 'B' Circuit Malfunction
Acura P1768	Automatic Transaxle Linear Solenoid Circuit Malfunction
Acura P1773	A/T Lockup Solenoid Valve 'B' Circuit Malfunction
Acura P1778	A/T Lockup Solenoid Valve 'C' Circuit Malfunction
Acura P1780	Problem in Shift Control System (Transmission is in Default Mode)
Acura P1786	A/T FAS Signal Circuit Malfunction
Acura P1787	A/T FFS Signal Circuit Malfunction
Acura P1788	A/T ATSDLA Signal Circuit Malfunction
Acura P1790	A/T Throttle Position Sensor Circuit Malfunction
Acura P1791	A/T Vehicle Speed Sensor Circuit Malfunction

Codes	Definition
Acura P1792	A/T Engine Coolant Temperature Sensor Circuit Malfunction
Acura P1793	A/T Manifold Absolute Pressure Sensor Circuit Malfunction
Acura P1794	A/T Barometric Pressure Sensor Circuit Malfunction
Acura P1795	A/T Accelerator Position Sensor Circuit Malfunction
Acura P1835	Kick Down Switch Circuit Low Input
Acura P1850	A/T Brake Band Apply Solenoid Circuit Malfunction
Acura P1860	Torque Converter Clutch PWM Solenoid Circuit Malfunction
Acura P1870	Transmission Component Slipping Malfunction