



GENERIC NETWORK CODES

Compiled by ***OBDCodex***



www.obdcodex.com

Codes	Definition
U0001	High Speed CAN Communication Bus
U0002	High Speed CAN Communication Bus Performance
U0003	High Speed CAN Communication Bus (+) Open
U0004	High Speed CAN Communication Bus (+) Low
U0005	High Speed CAN Communication Bus (+) High
U0006	High Speed CAN Communication Bus (-) Open
U0007	High Speed CAN Communication Bus (-) Low
U0008	High Speed CAN Communication Bus (-) High
U0009	High Speed CAN Communication Bus (-) shorted to Bus (+)
U000A	ISO/SAE Reserved
U000B	ISO/SAE Reserved
U000C	ISO/SAE Reserved
U000D	ISO/SAE Reserved
U000E	ISO/SAE Reserved
U000F	ISO/SAE Reserved
U0010	Medium Speed CAN Communication Bus
U0011	Medium Speed CAN Communication Bus Performance
U0012	Medium Speed CAN Communication Bus (+) Open
U0013	Medium Speed CAN Communication Bus (+) Low
U0014	Medium Speed CAN Communication Bus (+) High
U0015	Medium Speed CAN Communication Bus (-) Open
U0016	Medium Speed CAN Communication Bus (-) Low
U0017	Medium Speed CAN Communication Bus (-) High
U0018	Medium Speed CAN Communication Bus (-) shorted to Bus (+)
U0019	Low Speed CAN Communication Bus
U001A	ISO/SAE Reserved
U001B	ISO/SAE Reserved
U001C	ISO/SAE Reserved
U001D	ISO/SAE Reserved
U001E	ISO/SAE Reserved
U001F	ISO/SAE Reserved
U0020	Low Speed CAN Communication Bus Performance
U0021	Low Speed CAN Communication Bus (+) Open
U0022	Low Speed CAN Communication Bus (+) Low
U0023	Low Speed CAN Communication Bus (+) High
U0024	Low Speed CAN Communication Bus (-) Open
U0025	Low Speed CAN Communication Bus (-) Low
U0026	Low Speed CAN Communication Bus (-) High
U0027	Low Speed CAN Communication Bus (-) shorted to Bus (+)
U0028	Vehicle Communication Bus A
U0029	Vehicle Communication Bus A Performance
U002A	ISO/SAE Reserved
U002B	ISO/SAE Reserved
U002C	ISO/SAE Reserved

Codes	Definition
U002D	ISO/SAE Reserved
U002E	ISO/SAE Reserved
U002F	ISO/SAE Reserved
U0030	Vehicle Communication Bus A (+) Open
U0031	Vehicle Communication Bus A (+) Low
U0032	Vehicle Communication Bus A (+) High
U0033	Vehicle Communication Bus A (-) Open
U0034	Vehicle Communication Bus A (-) Low
U0035	Vehicle Communication Bus A (-) High
U0036	Vehicle Communication Bus A (-) shorted to Bus A (+)
U0037	Vehicle Communication Bus B
U0038	Vehicle Communication Bus B Performance
U0039	Vehicle Communication Bus B (+) Open
U003A	ISO/SAE Reserved
U003B	ISO/SAE Reserved
U003C	ISO/SAE Reserved
U003D	ISO/SAE Reserved
U003E	ISO/SAE Reserved
U003F	ISO/SAE Reserved
U0040	Vehicle Communication Bus B (+) Low
U0041	Vehicle Communication Bus B (+) High
U0042	Vehicle Communication Bus B (-) Open
U0043	Vehicle Communication Bus B (-) Low
U0044	Vehicle Communication Bus B (-) High/p>
U0045	Vehicle Communication Bus B (-) shorted to Bus B (+)
U0046	Vehicle Communication Bus C
U0047	Vehicle Communication Bus C Performance
U0048	Vehicle Communication Bus C (+) Open
U0049	Vehicle Communication Bus C (+) Low
U004A	ISO/SAE Reserved
U004B	ISO/SAE Reserved
U004C	ISO/SAE Reserved
U004D	ISO/SAE Reserved
U004E	ISO/SAE Reserved
U004F	ISO/SAE Reserved
U0050	Vehicle Communication Bus C (+) High
U0051	Vehicle Communication Bus C (-) Open
U0052	Vehicle Communication Bus C (-) Low
U0053	Vehicle Communication Bus C (-) High
U0054	Vehicle Communication Bus C (-) shorted to Bus C (+)
U0055	Vehicle Communication Bus D
U0056	Vehicle Communication Bus D Performance
U0057	Vehicle Communication Bus D (+) Open
U0058	Vehicle Communication Bus D (+) Low

Codes	Definition
U0059	Vehicle Communication Bus D (+) High
U005A	ISO/SAE Reserved
U005B	ISO/SAE Reserved
U005C	ISO/SAE Reserved
U005D	ISO/SAE Reserved
U005E	ISO/SAE Reserved
U005F	ISO/SAE Reserved
U0060	Vehicle Communication Bus D (-) Open
U0061	Vehicle Communication Bus D (-) Low
U0062	Vehicle Communication Bus D (-) High
U0063	Vehicle Communication Bus D (-) shorted to Bus D (+)
U0064	Vehicle Communication Bus E
U0065	Vehicle Communication Bus E Performance
U0066	Vehicle Communication Bus E (+) Open
U0067	Vehicle Communication Bus E (+) Low
U0068	Vehicle Communication Bus E (+) High
U0069	Vehicle Communication Bus E (-) Open
U006A	ISO/SAE Reserved
U006B	ISO/SAE Reserved
U006C	ISO/SAE Reserved
U006D	ISO/SAE Reserved
U006E	ISO/SAE Reserved
U006F	ISO/SAE Reserved
U0070	Vehicle Communication Bus E (-) Low
U0071	Vehicle Communication Bus E (-) High
U0072	Vehicle Communication Bus E (-) shorted to Bus E (+)
U0073	Control Module Communication Bus "A" Off
U0074	Control Module Communication Bus "B" Off
U0075	ISO/SAE Reserved
U0077	ISO/SAE Reserved
U0078	ISO/SAE Reserved
U0079	ISO/SAE Reserved
U007A	ISO/SAE Reserved
U007B	ISO/SAE Reserved
U007C	ISO/SAE Reserved
U007D	ISO/SAE Reserved
U007E	ISO/SAE Reserved
U007F	ISO/SAE Reserved
U0080	ISO/SAE Reserved
U0081	ISO/SAE Reserved
U0082	ISO/SAE Reserved
U0083	ISO/SAE Reserved
U0084	ISO/SAE Reserved
U0085	ISO/SAE Reserved

Codes	Definition
U0086	ISO/SAE Reserved
U0087	ISO/SAE Reserved
U0088	ISO/SAE Reserved
U0089	ISO/SAE Reserved
U008A	ISO/SAE Reserved
U008B	ISO/SAE Reserved
U008C	ISO/SAE Reserved
U008D	ISO/SAE Reserved
U008E	ISO/SAE Reserved
U008F	ISO/SAE Reserved
U0090	ISO/SAE Reserved
U0091	ISO/SAE Reserved
U0092	ISO/SAE Reserved
U0093	ISO/SAE Reserved
U0094	ISO/SAE Reserved
U0095	ISO/SAE Reserved
U0096	ISO/SAE Reserved
U0097	ISO/SAE Reserved
U0098	ISO/SAE Reserved
U0099	ISO/SAE Reserved
U009A	ISO/SAE Reserved
U009B	ISO/SAE Reserved
U009C	ISO/SAE Reserved
U009D	ISO/SAE Reserved
U009E	ISO/SAE Reserved
U009F	ISO/SAE Reserved
U00A0	ISO/SAE Reserved
U00A1	ISO/SAE Reserved
U00A2	ISO/SAE Reserved
U00A3	ISO/SAE Reserved
U00A4	ISO/SAE Reserved
U00A5	ISO/SAE Reserved
U00A6	ISO/SAE Reserved
U00A7	ISO/SAE Reserved
U00A8	ISO/SAE Reserved
U00A9	ISO/SAE Reserved
U00AA	ISO/SAE Reserved
U00AB	ISO/SAE Reserved
U00AC	ISO/SAE Reserved
U00AD	ISO/SAE Reserved
U00AE	ISO/SAE Reserved
U00AF	ISO/SAE Reserved
U00B0	ISO/SAE Reserved
U00B1	ISO/SAE Reserved

Codes	Definition
U00B2	ISO/SAE Reserved
U00B3	ISO/SAE Reserved
U00B4	ISO/SAE Reserved
U00B5	ISO/SAE Reserved
U00B6	ISO/SAE Reserved
U00B7	ISO/SAE Reserved
U00B8	ISO/SAE Reserved
U00B9	ISO/SAE Reserved
U00BA	ISO/SAE Reserved
U00BB	ISO/SAE Reserved
U00BC	ISO/SAE Reserved
U00BD	ISO/SAE Reserved
U00BE	ISO/SAE Reserved
U00BF	ISO/SAE Reserved
U00C0	ISO/SAE Reserved
U00C1	ISO/SAE Reserved
U00C2	ISO/SAE Reserved
U00C3	ISO/SAE Reserved
U00C4	ISO/SAE Reserved
U00C5	ISO/SAE Reserved
U00C6	ISO/SAE Reserved
U00C7	ISO/SAE Reserved
U00C8	ISO/SAE Reserved
U00C9	ISO/SAE Reserved
U00CA	ISO/SAE Reserved
U00CB	ISO/SAE Reserved
U00CC	ISO/SAE Reserved
U00CD	ISO/SAE Reserved
U00CE	ISO/SAE Reserved
U00CF	ISO/SAE Reserved
U00D0	ISO/SAE Reserved
U00D1	ISO/SAE Reserved
U00D2	ISO/SAE Reserved
U00D3	ISO/SAE Reserved
U00D4	ISO/SAE Reserved
U00D5	ISO/SAE Reserved
U00D6	ISO/SAE Reserved
U00D7	ISO/SAE Reserved
U00D8	ISO/SAE Reserved
U00D9	ISO/SAE Reserved
U00DA	ISO/SAE Reserved
U00DB	ISO/SAE Reserved
U00DC	ISO/SAE Reserved
U00DD	ISO/SAE Reserved

Codes	Definition
U00DE	ISO/SAE Reserved
U00DF	ISO/SAE Reserved
U00E0	ISO/SAE Reserved
U00E1	ISO/SAE Reserved
U00E2	ISO/SAE Reserved
U00E3	ISO/SAE Reserved
U00E4	ISO/SAE Reserved
U00E5	ISO/SAE Reserved
U00E6	ISO/SAE Reserved
U00E7	ISO/SAE Reserved
U00E8	ISO/SAE Reserved
U00E9	ISO/SAE Reserved
U00EA	ISO/SAE Reserved
U00EB	ISO/SAE Reserved
U00EC	ISO/SAE Reserved
U00ED	ISO/SAE Reserved
U00EE	ISO/SAE Reserved
U00EF	ISO/SAE Reserved
U00F0	ISO/SAE Reserved
U00F1	ISO/SAE Reserved
U00F2	ISO/SAE Reserved
U00F3	ISO/SAE Reserved
U00F4	ISO/SAE Reserved
U00F5	ISO/SAE Reserved
U00F6	ISO/SAE Reserved
U00F7	ISO/SAE Reserved
U00F8	ISO/SAE Reserved
U00F9	ISO/SAE Reserved
U00FA	ISO/SAE Reserved
U00FB	ISO/SAE Reserved
U00FC	ISO/SAE Reserved
U00FD	ISO/SAE Reserved
U00FE	ISO/SAE Reserved
U00FF	ISO/SAE Reserved
U0100	Lost Communication With ECM/PCM "A"
U0101	Lost Communication with Transmission Control Module (TCM)
U0102	Lost Communication with Transfer Case Control Module (TCCM)
U0103	Lost Communication with Gear Shift Control (GSC) Module
U0104	Lost Communication with Cruise Control Module (CCM)
U0105	Lost Communication with Fuel Injector Control Module (FICM)
U0106	Lost Communication with Glow Plug Control Module (GPCM)
U0107	Lost Communication with Throttle Actuator Control (TAC) Module
U0108	Lost Communication with Alternate Fuel Control Module (AFCM)
U0109	Lost Communication with Fuel Pump Control Module (FPCM)

Codes	Definition
U010A	Lost Communication With Exhaust Gas Recirculation Control Module A
U010B	Lost Communication With Exhaust Gas Recirculation Control Module B
U010C	Lost Communication With Turbocharger / Supercharger Control Module A
U010D	Lost Communication With Turbocharger / Supercharger Control Module B
U010E	Lost Communication With Reductant Control Module
U010F	Lost Communication With Air Conditioning Control Module
U0110	Lost Communication with Drive Motor Control Module (DMCM)
U0111	Lost Communication with Battery Energy Control Module "A"
U0112	Lost Communication with Battery Energy Control Module "B"
U0113	Lost Communication with Variable Valve Event and Lift (VVEL) Control Module
U0114	Lost Communication with Four-Wheel Drive Clutch Control Module
U0115	Lost Communication With ECM/PCM "B"
U0116	Lost Communication with Coolant Temperature Control Module
U0117	Lost Communication with PTO Control Module
U0118	Lost Communication with Fuel Additive Control Module
U0119	Lost Communication with Fuel Cell Control Module
U011A	Lost Communication With Exhaust Gas Sensor Module
U011B	Lost Communication With Rocker Arm Control Module A
U011C	Lost Communication With Rocker Arm Control Module B
U011D	Lost Communication With All Wheel Drive Control Module
U011E	ISO/SAE Reserved
U011F	ISO/SAE Reserved
U0120	Lost Communication with Starter Generator Control Module
U0121	Lost Communication With Anti-Lock Brake System (ABS) Control Module
U0122	Lost Communication With Vehicle Dynamics Control (VDC) Module
U0123	Lost Communication With Yaw Rate Sensor (YRS) Module
U0124	Lost Communication With Lateral Acceleration Sensor (LAS) Module
U0125	Lost Communication With Multi-Axis Acceleration Sensor (MAS) Module
U0126	Lost Communication With Steering Angle Sensor (SAS) Module
U0127	Lost Communication with Tire Pressure Monitor Module
U0128	Lost Communication with Park Brake Control Module (PBCM)
U0129	Lost Communication with Brake System Control Module (BSCM)
U012A	ISO/SAE Reserved
U012B	ISO/SAE Reserved
U012C	ISO/SAE Reserved
U012D	ISO/SAE Reserved
U012E	ISO/SAE Reserved
U012F	ISO/SAE Reserved
U0130	Lost Communication with Steering Effort Control Module
U0131	Lost Communication with Power Steering Control Module
U0132	Lost Communication with Ride Level Control Module
U0133	Lost Communication with Active Roll Control Module
U0134	Lost Communication with Rear Power Steering Control Module

Codes	Definition
U0135	Lost Communication with Front Differential Control Module
U0136	Lost Communication with Rear Differential Control Module
U0137	Lost Communication with Trailer Brake Control Module
U0138	Lost Communication with All Terrain Control Module
U0139	Lost Communication with Suspension Control Module "B"
U013A	ISO/SAE Reserved
U013B	ISO/SAE Reserved
U013C	ISO/SAE Reserved
U013D	ISO/SAE Reserved
U013E	ISO/SAE Reserved
U013F	ISO/SAE Reserved
U0140	Lost Communication With Body Control Module
U0141	Lost Communication With Body Control Module "A"
U0142	Lost Communication With Body Control Module "B"
U0143	Lost Communication With Body Control Module "C"
U0144	Lost Communication With Body Control Module "D"
U0145	Lost Communication With Body Control Module "E"
U0146	Lost Communication With Gateway "A"
U0147	Lost Communication With Gateway "B"
U0148	Lost Communication With Gateway "C"
U0149	Lost Communication With Gateway "D"
U014A	ISO/SAE Reserved
U014B	ISO/SAE Reserved
U014C	ISO/SAE Reserved
U014D	ISO/SAE Reserved
U014E	ISO/SAE Reserved
U014F	ISO/SAE Reserved
U0150	Lost Communication With Gateway "E"
U0151	Lost Communication with Restraints Control (RCM) Module
U0152	Lost Communication with Side Restraints Control Module (Left)
U0153	Lost Communication with Side Restraints Control Module (Right)
U0154	Lost Communication with Restraints Occupant Sensing Control Module
U0155	Lost Communication with Instrument Panel Control (IPC) Module
U0156	Lost Communication With Information Center A
U0157	Lost Communication With Information Center B
U0158	Lost Communication With Head Up Display
U0159	Lost Communication With Park Assist Control Module A
U015A	ISO/SAE Reserved
U015B	ISO/SAE Reserved
U015C	ISO/SAE Reserved
U015D	ISO/SAE Reserved
U015E	ISO/SAE Reserved
U015F	ISO/SAE Reserved
U0160	Lost Communication With Audible Alert Control Module

Codes	Definition
U0161	Lost Communication With Compass Module
U0162	Lost Communication With Navigation Display Module
U0163	Lost Communication With Navigation Control Module
U0164	Lost Communication With HVAC Control Module
U0165	Lost Communication With Rear HVAC Control Module
U0166	Lost Communication With Auxiliary Heater Control Module
U0167	Lost Communication With Vehicle Immobilizer Control Module
U0168	Lost Communication With Vehicle Security Control Module
U0169	Lost Communication With Sunroof Control Module
U016A	Lost Communication With Global Positioning System Module
U016B	ISO/SAE Reserved
U016C	ISO/SAE Reserved
U016D	ISO/SAE Reserved
U016E	ISO/SAE Reserved
U016F	ISO/SAE Reserved
U0170	Lost Communication With Restraints System Sensor A
U0171	Lost Communication With Restraints System Sensor B
U0172	Lost Communication With Restraints System Sensor C
U0173	Lost Communication With Restraints System Sensor D
U0174	Lost Communication With Restraints System Sensor E
U0175	Lost Communication With Restraints System Sensor F
U0176	Lost Communication With Restraints System Sensor G
U0177	Lost Communication With Restraints System Sensor H
U0178	Lost Communication With Restraints System Sensor I
U0179	Lost Communication With Restraints System Sensor J
U017A	Lost Communication With Restraints System Sensor K
U017B	Lost Communication With Restraints System Sensor L
U017C	Lost Communication With Restraints System Sensor M
U017D	Lost Communication With Restraints System Sensor N
U017E	Lost Communication With Seat Belt Pretensioner Module A
U017F	Lost Communication With Seat Belt Pretensioner Module B
U0180	Lost Communication With Automatic Lighting Control Module
U0181	Lost Communication With Dynamic Headlight Leveling Control Module
U0182	Lost Communication With Lighting Control Module - Front
U0183	Lost Communication With Lighting Control Module - Rear
U0184	Lost Communication With Radio
U0185	Lost Communication With Antenna Control Module
U0186	Lost Communication With AMP Unit A
U0187	Lost Communication With Digital Disc Player/Changer Module A
U0188	Lost Communication With Digital Disc Player/Changer Module B
U0189	Lost Communication With Digital Disc Player/Changer Module C
U018A	ISO/SAE Reserved
U018B	ISO/SAE Reserved
U018C	ISO/SAE Reserved

Codes	Definition
U018D	ISO/SAE Reserved
U018E	ISO/SAE Reserved
U018F	ISO/SAE Reserved
U0190	Lost Communication With Digital Disc Player/Changer Module D
U0191	Lost Communication With Television
U0192	Lost Communication With Personal Computer
U0193	Lost Communication With Digital Audio Control Module A
U0194	Lost Communication With Digital Audio Control Module B
U0195	Lost Communication With Subscription Entertainment Receiver Module
U0196	Lost Communication With Rear Seat Entertainment Control Module
U0197	Lost Communication With Telephone Control Module
U0198	Lost Communication With Telematic Control Module
U0199	Lost Communication With Door Control Module A
U019A	ISO/SAE Reserved
U019B	ISO/SAE Reserved
U019C	ISO/SAE Reserved
U019D	ISO/SAE Reserved
U019E	ISO/SAE Reserved
U019F	ISO/SAE Reserved
U01A0	ISO/SAE Reserved
U01A1	ISO/SAE Reserved
U01A2	ISO/SAE Reserved
U01A3	ISO/SAE Reserved
U01A4	ISO/SAE Reserved
U01A5	ISO/SAE Reserved
U01A6	ISO/SAE Reserved
U01A7	ISO/SAE Reserved
U01A8	ISO/SAE Reserved
U01A9	ISO/SAE Reserved
U01AA	ISO/SAE Reserved
U01AB	ISO/SAE Reserved
U01AC	ISO/SAE Reserved
U01AD	ISO/SAE Reserved
U01AE	ISO/SAE Reserved
U01AF	ISO/SAE Reserved
U01B0	ISO/SAE Reserved
U01B1	ISO/SAE Reserved
U01B2	ISO/SAE Reserved
U01B3	ISO/SAE Reserved
U01B4	ISO/SAE Reserved
U01B5	ISO/SAE Reserved
U01B6	ISO/SAE Reserved
U01B7	ISO/SAE Reserved
U01B8	ISO/SAE Reserved

Codes	Definition
U01B9	ISO/SAE Reserved
U01BA	ISO/SAE Reserved
U01BB	ISO/SAE Reserved
U01BC	ISO/SAE Reserved
U01BD	ISO/SAE Reserved
U01BE	ISO/SAE Reserved
U01BF	ISO/SAE Reserved
U01C0	ISO/SAE Reserved
U01C1	ISO/SAE Reserved
U01C2	ISO/SAE Reserved
U01C3	ISO/SAE Reserved
U01C4	ISO/SAE Reserved
U01C5	ISO/SAE Reserved
U01C6	ISO/SAE Reserved
U01C7	ISO/SAE Reserved
U01C8	ISO/SAE Reserved
U01C9	ISO/SAE Reserved
U01CA	ISO/SAE Reserved
U01CB	ISO/SAE Reserved
U01CC	ISO/SAE Reserved
U01CD	ISO/SAE Reserved
U01CE	ISO/SAE Reserved
U01CF	ISO/SAE Reserved
U01D0	ISO/SAE Reserved
U01D1	ISO/SAE Reserved
U01D2	ISO/SAE Reserved
U01D3	ISO/SAE Reserved
U01D4	ISO/SAE Reserved
U01D5	ISO/SAE Reserved
U01D6	ISO/SAE Reserved
U01D7	ISO/SAE Reserved
U01D8	ISO/SAE Reserved
U01D9	ISO/SAE Reserved
U01DA	ISO/SAE Reserved
U01DB	ISO/SAE Reserved
U01DC	ISO/SAE Reserved
U01DD	ISO/SAE Reserved
U01DE	ISO/SAE Reserved
U01DF	ISO/SAE Reserved
U01E0	ISO/SAE Reserved
U01E1	ISO/SAE Reserved
U01E2	ISO/SAE Reserved
U01E3	ISO/SAE Reserved
U01E4	ISO/SAE Reserved

Codes	Definition
U01E5	ISO/SAE Reserved
U01E6	ISO/SAE Reserved
U01E7	ISO/SAE Reserved
U01E8	ISO/SAE Reserved
U01E9	ISO/SAE Reserved
U01EA	ISO/SAE Reserved
U01EB	ISO/SAE Reserved
U01EC	ISO/SAE Reserved
U01ED	ISO/SAE Reserved
U01EE	ISO/SAE Reserved
U01EF	ISO/SAE Reserved
U01F0	ISO/SAE Reserved
U01F1	ISO/SAE Reserved
U01F2	ISO/SAE Reserved
U01F3	ISO/SAE Reserved
U01F4	ISO/SAE Reserved
U01F5	ISO/SAE Reserved
U01F6	ISO/SAE Reserved
U01F7	ISO/SAE Reserved
U01F8	ISO/SAE Reserved
U01F9	ISO/SAE Reserved
U01FA	ISO/SAE Reserved
U01FB	ISO/SAE Reserved
U01FC	ISO/SAE Reserved
U01FD	ISO/SAE Reserved
U01FE	ISO/SAE Reserved
U01FF	ISO/SAE Reserved
U0200	Lost Communication With Door Control Module B
U0201	Lost Communication With Door Control Module C
U0202	Lost Communication With Door Control Module D
U0203	Lost Communication With Door Control Module E
U0204	Lost Communication With Door Control Module F
U0205	Lost Communication With Door Control Module G
U0206	Lost Communication With Folding Top Control Module
U0207	Lost Communication With Movable Roof Control Module
U0208	Lost Communication With Seat Control Module A
U0209	Lost Communication With Seat Control Module B
U020A	ISO/SAE Reserved
U020B	ISO/SAE Reserved
U020C	ISO/SAE Reserved
U020D	ISO/SAE Reserved
U020E	ISO/SAE Reserved
U020F	ISO/SAE Reserved
U0210	Lost Communication With Seat Control Module C

Codes	Definition
U0211	Lost Communication With Seat Control Module D
U0212	Lost Communication With Steering Column Control Module
U0213	Lost Communication With Mirror Control Module
U0214	Lost Communication With Remote Function Actuation
U0215	Lost Communication With Door Switch A
U0216	Lost Communication With Door Switch B
U0217	Lost Communication With Door Switch C
U0218	Lost Communication With Door Switch D
U0219	Lost Communication With Door Switch E
U021A	ISO/SAE Reserved
U021B	ISO/SAE Reserved
U021C	ISO/SAE Reserved
U021D	ISO/SAE Reserved
U021E	ISO/SAE Reserved
U021F	ISO/SAE Reserved
U0220	Lost Communication With Door Switch F
U0221	Lost Communication With Door Switch G
U0222	Lost Communication With Door Window Motor A
U0223	Lost Communication With Door Window Motor B
U0224	Lost Communication With Door Window Motor C
U0225	Lost Communication With Door Window Motor D
U0226	Lost Communication With Door Window Motor E
U0227	Lost Communication With Door Window Motor F
U0228	Lost Communication With Door Window Motor G
U0229	Lost Communication With Heated Steering Wheel Module
U022A	ISO/SAE Reserved
U022B	ISO/SAE Reserved
U022C	ISO/SAE Reserved
U022D	ISO/SAE Reserved
U022E	ISO/SAE Reserved
U022F	ISO/SAE Reserved
U0230	Lost Communication With Rear Gate Module
U0231	Lost Communication With Rain Sensing Module
U0232	Lost Communication With Obstacle Detection Control Module - Left
U0233	Lost Communication With Obstacle Detection Control Module - Right
U0234	Lost Communication With Convenience Recall Module
U0235	Lost Communication With Cruise Control Front Distance Range Sensor
U0236	Lost Communication With Column Lock Module
U0237	Lost Communication With Digital Audio Control Module C
U0238	Lost Communication With Digital Audio Control Module D
U0239	Lost Communication With Entrapment Control Module A
U023A	Lost Communication With Image Processing Module A
U023B	Lost Communication With Image Processing Module B
U023C	Lost Communication With Image Processing Module C

Codes	Definition
U023D	Lost Communication With Cruise Control Front Distance Range Sensor Left
U023E	Lost Communication With Cruise Control Front Distance Range Sensor Right
U023F	ISO/SAE Reserved
U0240	Lost Communication With Entrapment Control Module B
U0241	Lost Communication With Headlamp Control Module A
U0242	Lost Communication With Headlamp Control Module B
U0243	Lost Communication With Park Assist Control Module B
U0244	Lost Communication With Running Board Control Module A
U0245	Lost Communication With Entertainment Control Module Front
U0246	Lost Communication With Seat Control Module E
U0247	Lost Communication With Seat Control Module F
U0248	Lost Communication With Remote Accessory Module
U0249	Lost Communication With Entertainment Control Module Rear B
U024A	Lost Communication With Interior Lighting Control Module
U024B	ISO/SAE Reserved
U024C	ISO/SAE Reserved
U024D	ISO/SAE Reserved
U024E	ISO/SAE Reserved
U024F	ISO/SAE Reserved
U0250	Lost Communication With Impact Classification System Module
U0251	Lost Communication With Running Board Control Module B
U0252	Lost Communication With Lighting Control Module Rear B
U0253	Lost Communication With Accessory Protocol Interface Module
U0254	Lost Communication With Remote Start Module
U0255	Lost Communication With Front Display Interface Module
U0256	Lost Communication With Front Controls Interface Module "A"
U0257	Lost Communication With Front Controls/Display Interface Module
U0258	Lost Communication With Radio Transceiver
U0259	Lost Communication With Special Purpose Vehicle Control Module A
U025A	Lost Communication With Special Purpose Vehicle Control Module B
U025B	Lost Communication With Special Purpose Vehicle Control Module C
U025C	Lost Communication With Special Purpose Vehicle Control Module D
U025D	Lost Communication With Front Controls Interface Module "B"
U025E	ISO/SAE Reserved
U025F	ISO/SAE Reserved
U0260	Lost Communication With Seat Control Switch Module A
U0261	Lost Communication With Seat Control Switch Module B
U0262	Lost Communication With AMP Unit B
U0263	Lost Communication With Speech Recognition Module
U0264	Lost Communication With Camera Module Rear
U0265	ISO/SAE Reserved
U0266	ISO/SAE Reserved
U0267	ISO/SAE Reserved
U0268	ISO/SAE Reserved

Codes	Definition
U0269	ISO/SAE Reserved
U026A	ISO/SAE Reserved
U026B	ISO/SAE Reserved
U026C	ISO/SAE Reserved
U026D	ISO/SAE Reserved
U026E	ISO/SAE Reserved
U026F	ISO/SAE Reserved
U0270	ISO/SAE Reserved
U0271	ISO/SAE Reserved
U0272	ISO/SAE Reserved
U0273	ISO/SAE Reserved
U0274	ISO/SAE Reserved
U0275	ISO/SAE Reserved
U0276	ISO/SAE Reserved
U0277	ISO/SAE Reserved
U0278	ISO/SAE Reserved
U0279	ISO/SAE Reserved
U027A	ISO/SAE Reserved
U027B	ISO/SAE Reserved
U027C	ISO/SAE Reserved
U027D	ISO/SAE Reserved
U027E	ISO/SAE Reserved
U027F	ISO/SAE Reserved
U0280	ISO/SAE Reserved
U0281	ISO/SAE Reserved
U0282	ISO/SAE Reserved
U0283	ISO/SAE Reserved
U0284	ISO/SAE Reserved
U0285	ISO/SAE Reserved
U0286	Lost Communication With Radiator Anti Tamper Device
U0287	Lost Communication With Transmission Fluid Pump Module
U0288	Lost Communication With DC to AC Converter Control Module-A
U0289	Lost Communication With DC to AC Converter Control Module-B
U028A	ISO/SAE Reserved
U028B	ISO/SAE Reserved
U028C	ISO/SAE Reserved
U028D	ISO/SAE Reserved
U028E	ISO/SAE Reserved
U028F	ISO/SAE Reserved
U0290	ISO/SAE Reserved
U0291	Lost Communication with Gear Shift Control (GSC-B) Module B
U0292	Lost Communication with Drive Motor Control Module B
U0293	Lost Communication With Hybrid Powertrain Control Module
U0294	Lost Communication With Powertrain Control Monitor Module

Codes	Definition
U0295	Lost Communication With AC to AC Converter Control Module
U0296	Lost Communication With AC to DC Converter Control Module-A
U0297	Lost Communication With AC to DC Converter Control Module-B
U0298	Lost Communication With DC to DC Converter Control Module-A
U0299	Lost Communication With DC to DC Converter Control Module-B
U029A	Lost Communication With Hybrid Battery Pack Sensor Module
U029B	Lost Communication with Drive Motor Control Module C
U029C	Lost Communication with Drive Motor Control Module D
U029D	Lost Communication With NOX Sensor A
U029E	Lost Communication With NOX Sensor B
U029F	ISO/SAE Reserved
U02A0	ISO/SAE Reserved
U02A1	ISO/SAE Reserved
U02A2	ISO/SAE Reserved
U02A3	ISO/SAE Reserved
U02A4	ISO/SAE Reserved
U02A5	ISO/SAE Reserved
U02A6	ISO/SAE Reserved
U02A7	ISO/SAE Reserved
U02A8	ISO/SAE Reserved
U02A9	ISO/SAE Reserved
U02AA	ISO/SAE Reserved
U02AB	ISO/SAE Reserved
U02AC	ISO/SAE Reserved
U02AD	ISO/SAE Reserved
U02AE	ISO/SAE Reserved
U02AF	ISO/SAE Reserved
U02B0	ISO/SAE Reserved
U02B1	ISO/SAE Reserved
U02B2	ISO/SAE Reserved
U02B3	ISO/SAE Reserved
U02B4	ISO/SAE Reserved
U02B5	ISO/SAE Reserved
U02B6	ISO/SAE Reserved
U02B7	ISO/SAE Reserved
U02B8	ISO/SAE Reserved
U02B9	ISO/SAE Reserved
U02BA	ISO/SAE Reserved
U02BB	ISO/SAE Reserved
U02BC	ISO/SAE Reserved
U02BD	ISO/SAE Reserved
U02BE	ISO/SAE Reserved
U02BF	ISO/SAE Reserved
U02C0	ISO/SAE Reserved

Codes	Definition
U02C1	ISO/SAE Reserved
U02C2	ISO/SAE Reserved
U02C3	ISO/SAE Reserved
U02C4	ISO/SAE Reserved
U02C5	ISO/SAE Reserved
U02C6	ISO/SAE Reserved
U02C7	ISO/SAE Reserved
U02C8	ISO/SAE Reserved
U02C9	ISO/SAE Reserved
U02CA	ISO/SAE Reserved
U02CB	ISO/SAE Reserved
U02CC	ISO/SAE Reserved
U02CD	ISO/SAE Reserved
U02CE	ISO/SAE Reserved
U02CF	ISO/SAE Reserved
U02D0	ISO/SAE Reserved
U02D1	ISO/SAE Reserved
U02D2	ISO/SAE Reserved
U02D3	ISO/SAE Reserved
U02D4	ISO/SAE Reserved
U02D5	ISO/SAE Reserved
U02D6	ISO/SAE Reserved
U02D7	ISO/SAE Reserved
U02D8	ISO/SAE Reserved
U02D9	ISO/SAE Reserved
U02DA	ISO/SAE Reserved
U02DB	ISO/SAE Reserved
U02DC	ISO/SAE Reserved
U02DD	ISO/SAE Reserved
U02DE	ISO/SAE Reserved
U02DF	ISO/SAE Reserved
U02E0	ISO/SAE Reserved
U02E1	ISO/SAE Reserved
U02E2	ISO/SAE Reserved
U02E3	ISO/SAE Reserved
U02E4	ISO/SAE Reserved
U02E5	ISO/SAE Reserved
U02E6	ISO/SAE Reserved
U02E7	ISO/SAE Reserved
U02E8	ISO/SAE Reserved
U02E9	ISO/SAE Reserved
U02EA	ISO/SAE Reserved
U02EB	ISO/SAE Reserved
U02EC	ISO/SAE Reserved

Codes	Definition
U02ED	ISO/SAE Reserved
U02EE	ISO/SAE Reserved
U02EF	ISO/SAE Reserved
U02F0	ISO/SAE Reserved
U02F1	ISO/SAE Reserved
U02F2	ISO/SAE Reserved
U02F3	ISO/SAE Reserved
U02F4	ISO/SAE Reserved
U02F5	ISO/SAE Reserved
U02F6	ISO/SAE Reserved
U02F7	ISO/SAE Reserved
U02F8	ISO/SAE Reserved
U02F9	ISO/SAE Reserved
U02FA	ISO/SAE Reserved
U02FB	ISO/SAE Reserved
U02FC	ISO/SAE Reserved
U02FD	ISO/SAE Reserved
U02FE	ISO/SAE Reserved
U02FF	ISO/SAE Reserved
U0300	Internal Control Module Software Incompatibility
U0301	Software Incompatibility With ECM/PCM
U0302	Software Incompatibility With Transmission Control Module
U0303	Software Incompatibility With Transfer Case Control Module
U0304	Software Incompatibility With Gear Shift Control Module "A"
U0305	Software Incompatibility With Cruise Control Module
U0306	Software Incompatibility With Fuel Injector Control Module
U0307	Software Incompatibility With Glow Plug Control Module
U0308	Software Incompatibility With Throttle Actuator Control Module
U0309	Software Incompatibility With Alternative Fuel Control Module
U030A	ISO/SAE Reserved
U030B	ISO/SAE Reserved
U030C	ISO/SAE Reserved
U030D	ISO/SAE Reserved
U030E	ISO/SAE Reserved
U030F	ISO/SAE Reserved
U0310	Software Incompatibility With Fuel Pump Control Module
U0311	Software Incompatibility With Drive Motor Control Module (DMCM)
U0312	Software Incompatibility With Battery Energy Control Module A
U0313	Software Incompatibility With Battery Energy Control Module B
U0314	Software Incompatibility With Four-Wheel Drive Clutch Control Module
U0315	Software Incompatibility With Anti-Lock Brake System Control Module
U0316	Software Incompatibility With Vehicle Dynamics Control Module
U0317	Software Incompatibility With Park Brake Control Module
U0318	Software Incompatibility With Brake System Control Module

Codes	Definition
U0319	Software Incompatibility With Steering Effort Control Module
U031A	ISO/SAE Reserved
U031B	ISO/SAE Reserved
U031C	ISO/SAE Reserved
U031D	ISO/SAE Reserved
U031E	ISO/SAE Reserved
U031F	ISO/SAE Reserved
U0320	Software Incompatibility With Power Steering Control Module
U0321	Software Incompatibility With Suspension Control Module "A"
U0322	Software Incompatibility With Body Control Module (BCM)
U0323	Software Incompatibility With Instrument Panel Control Module
U0324	Software Incompatibility With HVAC Control Module
U0325	Software Incompatibility With Auxiliary Heater Control Module
U0326	Software Incompatibility With Vehicle Immobilizer Control Module
U0327	Software Incompatibility With Vehicle Security Control Module
U0328	Software Incompatibility With Steering Angle Sensor Module
U0329	Software Incompatibility With Steering Column Control Module
U032A	ISO/SAE Reserved
U032B	ISO/SAE Reserved
U032C	ISO/SAE Reserved
U032D	ISO/SAE Reserved
U032E	ISO/SAE Reserved
U032F	ISO/SAE Reserved
U0330	Software Incompatibility With Tire Pressure Monitor Module
U0331	Software Incompatibility With Body Control Module (BCM) "A"
U0332	Software Incompatibility With Multi-axis Acceleration Sensor Module
U0333	Software Incompatibility With Gear Shift Control Module "B"
U0334	Software Incompatibility With Radio
U0335	Software Incompatibility With Hybrid Battery Pack Sensor Module
U0336	Software Incompatibility with Restraints Control Module
U0337	ISO/SAE Reserved
U0338	ISO/SAE Reserved
U0339	ISO/SAE Reserved
U034A	ISO/SAE Reserved
U034B	ISO/SAE Reserved
U034C	ISO/SAE Reserved
U034D	ISO/SAE Reserved
U034E	ISO/SAE Reserved
U034F	ISO/SAE Reserved
U0350	ISO/SAE Reserved
U0351	ISO/SAE Reserved
U0352	ISO/SAE Reserved
U0353	ISO/SAE Reserved
U0354	ISO/SAE Reserved

Codes	Definition
U0355	ISO/SAE Reserved
U0356	ISO/SAE Reserved
U0357	ISO/SAE Reserved
U0358	ISO/SAE Reserved
U0359	ISO/SAE Reserved
U035A	ISO/SAE Reserved
U035B	ISO/SAE Reserved
U035C	ISO/SAE Reserved
U035D	ISO/SAE Reserved
U0360	ISO/SAE Reserved
U0361	ISO/SAE Reserved
U0362	ISO/SAE Reserved
U0363	ISO/SAE Reserved
U0364	ISO/SAE Reserved
U0365	ISO/SAE Reserved
U0366	ISO/SAE Reserved
U0367	ISO/SAE Reserved
U0368	ISO/SAE Reserved
U0369	ISO/SAE Reserved
U036A	ISO/SAE Reserved
U036B	ISO/SAE Reserved
U036C	ISO/SAE Reserved
U036D	ISO/SAE Reserved
U036E	ISO/SAE Reserved
U036F	ISO/SAE Reserved
U0370	ISO/SAE Reserved
U0371	ISO/SAE Reserved
U0372	ISO/SAE Reserved
U0373	ISO/SAE Reserved
U0374	ISO/SAE Reserved
U0375	ISO/SAE Reserved
U0376	ISO/SAE Reserved
U0377	ISO/SAE Reserved
U0378	ISO/SAE Reserved
U0379	ISO/SAE Reserved
U037A	ISO/SAE Reserved
U037B	ISO/SAE Reserved
U037C	ISO/SAE Reserved
U037D	ISO/SAE Reserved
U037E	ISO/SAE Reserved
U037F	ISO/SAE Reserved
U0380	ISO/SAE Reserved
U0381	ISO/SAE Reserved
U0382	ISO/SAE Reserved

Codes	Definition
U0383	ISO/SAE Reserved
U0384	ISO/SAE Reserved
U0385	ISO/SAE Reserved
U0386	ISO/SAE Reserved
U0387	ISO/SAE Reserved
U0388	ISO/SAE Reserved
U0389	ISO/SAE Reserved
U038A	ISO/SAE Reserved
U038B	ISO/SAE Reserved
U038C	ISO/SAE Reserved
U038D	ISO/SAE Reserved
U038E	ISO/SAE Reserved
U038F	ISO/SAE Reserved
U0390	ISO/SAE Reserved
U0391	ISO/SAE Reserved
U0392	ISO/SAE Reserved
U0393	ISO/SAE Reserved
U0394	ISO/SAE Reserved
U0395	ISO/SAE Reserved
U0396	ISO/SAE Reserved
U0397	ISO/SAE Reserved
U0398	ISO/SAE Reserved
U0399	ISO/SAE Reserved
U039A	ISO/SAE Reserved
U039B	ISO/SAE Reserved
U039C	ISO/SAE Reserved
U039D	ISO/SAE Reserved
U039E	ISO/SAE Reserved
U039F	ISO/SAE Reserved
U03A0	ISO/SAE Reserved
U03A1	ISO/SAE Reserved
U03A2	ISO/SAE Reserved
U03A3	ISO/SAE Reserved
U03A4	ISO/SAE Reserved
U03A5	ISO/SAE Reserved
U03A6	ISO/SAE Reserved
U03A7	ISO/SAE Reserved
U03A8	ISO/SAE Reserved
U03A9	ISO/SAE Reserved
U03AA	ISO/SAE Reserved
U03AB	ISO/SAE Reserved
U03AC	ISO/SAE Reserved
U03AD	ISO/SAE Reserved
U03AE	ISO/SAE Reserved

Codes	Definition
U03AF	ISO/SAE Reserved
U03B0	ISO/SAE Reserved
U03B1	ISO/SAE Reserved
U03B2	ISO/SAE Reserved
U03B3	ISO/SAE Reserved
U03B4	ISO/SAE Reserved
U03B5	ISO/SAE Reserved
U03B6	ISO/SAE Reserved
U03B7	ISO/SAE Reserved
U03B8	ISO/SAE Reserved
U03B9	ISO/SAE Reserved
U03BA	ISO/SAE Reserved
U03BB	ISO/SAE Reserved
U03BC	ISO/SAE Reserved
U03BD	ISO/SAE Reserved
U03BE	ISO/SAE Reserved
U03BF	ISO/SAE Reserved
U03C0	ISO/SAE Reserved
U03C1	ISO/SAE Reserved
U03C2	ISO/SAE Reserved
U03C3	ISO/SAE Reserved
U03C4	ISO/SAE Reserved
U03C5	ISO/SAE Reserved
U03C6	ISO/SAE Reserved
U03C7	ISO/SAE Reserved
U03C8	ISO/SAE Reserved
U03C9	ISO/SAE Reserved
U03CA	ISO/SAE Reserved
U03CB	ISO/SAE Reserved
U03CC	ISO/SAE Reserved
U03CD	ISO/SAE Reserved
U03CE	ISO/SAE Reserved
U03CF	ISO/SAE Reserved
U03D0	ISO/SAE Reserved
U03D1	ISO/SAE Reserved
U03D2	ISO/SAE Reserved
U03D3	ISO/SAE Reserved
U03D4	ISO/SAE Reserved
U03D5	ISO/SAE Reserved
U03D6	ISO/SAE Reserved
U03D7	ISO/SAE Reserved
U03D8	ISO/SAE Reserved
U03D9	ISO/SAE Reserved
U03DA	ISO/SAE Reserved

Codes	Definition
U03DB	ISO/SAE Reserved
U03DC	ISO/SAE Reserved
U03DD	ISO/SAE Reserved
U03DE	ISO/SAE Reserved
U03DF	ISO/SAE Reserved
U03E0	ISO/SAE Reserved
U03E1	ISO/SAE Reserved
U03E2	ISO/SAE Reserved
U03E3	ISO/SAE Reserved
U03E4	ISO/SAE Reserved
U03E5	ISO/SAE Reserved
U03E6	ISO/SAE Reserved
U03E7	ISO/SAE Reserved
U03E8	ISO/SAE Reserved
U03E9	ISO/SAE Reserved
U03EA	ISO/SAE Reserved
U03EB	ISO/SAE Reserved
U03EC	ISO/SAE Reserved
U03ED	ISO/SAE Reserved
U03EE	ISO/SAE Reserved
U03EF	ISO/SAE Reserved
U03F0	ISO/SAE Reserved
U03F1	ISO/SAE Reserved
U03F2	ISO/SAE Reserved
U03F3	ISO/SAE Reserved
U03F4	ISO/SAE Reserved
U03F5	ISO/SAE Reserved
U03F6	ISO/SAE Reserved
U03F7	ISO/SAE Reserved
U03F8	ISO/SAE Reserved
U03F9	ISO/SAE Reserved
U03FA	ISO/SAE Reserved
U03FB	ISO/SAE Reserved
U03FC	ISO/SAE Reserved
U03FD	ISO/SAE Reserved
U03FE	ISO/SAE Reserved
U03FF	ISO/SAE Reserved
U0400	ISO/SAE Reserved
U0401	Invalid Data Received From ECM/PCM "A"
U0402	Invalid Data Received From Transmission Control Module (TCM)
U0403	Invalid Data Received From Transfer Case Control Module
U0404	Invalid Data Received From Gear Shift Control Module "A"
U0405	Invalid Data Received From Cruise Control Module
U0406	Invalid Data Received From Fuel Injector Control Module

Codes	Definition
U0407	Invalid Data Received From Glow Plug Control Module
U0408	Invalid Data Received From Throttle Actuator Control Module
U0409	Invalid Data Received From Alternative Fuel Control Module
U040A	Invalid Data Received From Air Conditioning (A/C) Control Module
U040B	Invalid Data Received From Exhaust Gas Recirculation Control Module "A"
U040C	Invalid Data Received From Exhaust Gas Recirculation Control Module "B"
U040D	Invalid Data Received From Turbocharger/Supercharger Control Module "A"
U040E	Invalid Data Received From Turbocharger/Supercharger Control Module "B"
U040F	Invalid Data Received From Reductant Control Module
U0410	Invalid Data Received From Fuel Pump Control Module
U0411	Invalid Data Received From Drive Motor Control Module (DMCM) "A"
U0412	Invalid Data Received From Battery Energy Control Module "A"
U0413	Invalid Data Received From Battery Energy Control Module "B"
U0414	Invalid Data Received From Four-Wheel Drive Clutch Control Module
U0415	Invalid Data Received From Anti-Lock Brake System (ABS) Control Module
U0416	Invalid Data Received From Vehicle Dynamics Control Module
U0417	Invalid Data Received From Park Brake Control Module
U0418	Invalid Data Received From Brake System Control Module
U0419	Invalid Data Received From Steering Effort Control Module
U041A	ISO/SAE Reserved
U041B	Invalid Data Received From Exhaust Gas Sensor Module
U041C	Invalid Data Received From Rocker Arm Control Module "A"
U041D	Invalid Data Received From Rocker Arm Control Module "B"
U041E	Invalid Data Received From All Wheel Drive (AWD) Control Module
U041F	ISO/SAE Reserved
U0420	Invalid Data Received From Power Steering Control Module
U0421	Invalid Data Received From Suspension Control Module "A"
U0422	Invalid Data Received From Body Control Module (BCM)
U0423	Invalid Data Received From Instrument Panel Cluster Control
U0424	Invalid Data Received From HVAC Control Module
U0425	Invalid Data Received From Auxiliary Heater Control Module
U0426	Invalid Data Received From Vehicle Immobilizer Control Module
U0427	Invalid Data Received From Vehicle Security Control Module
U0428	Invalid Data Received From Steering Angle Sensor Module
U0429	Invalid Data Received From Steering Column Control Module
U042A	ISO/SAE Reserved
U042B	ISO/SAE Reserved
U042C	ISO/SAE Reserved
U042D	ISO/SAE Reserved
U042E	ISO/SAE Reserved
U042F	ISO/SAE Reserved
U0430	Invalid Data Received From Tire Pressure Monitor Module
U0431	Invalid Data Received From Body Control Module (BCM) "A"
U0432	Invalid Data Received From Multi-axis Acceleration Sensor Module

Codes	Definition
U0433	Invalid Data Received From Cruise Control Front Distance Range Sensor
U0434	Invalid Data Received From Active Roll Control Module
U0435	Invalid Data Received From Power Steering Control Module Rear
U0436	Invalid Data Received From Differential Control Module Front
U0437	Invalid Data Received From Differential Control Module Rear
U0438	Invalid Data Received From Trailer Brake Control Module
U0439	Invalid Data Received From All Terrain Control Module
U043A	Invalid Data Received From Suspension Control Module "B"
U043B	Invalid Data Received From Cruise Control Front Distance Range Sensor
U043C	Invalid Data Received From Cruise Control Front Distance Range Sensor
U043D	ISO/SAE Reserved
U043E	ISO/SAE Reserved
U043F	ISO/SAE Reserved
U0440	ISO/SAE Reserved
U0441	Invalid Data Received From Emissions Critical Control Information
U0442	Invalid Data Received From ECM/PCM "B"
U0443	Invalid Data Received From Body Control Module (BCM) "B"
U0444	Invalid Data Received From Body Control Module (BCM) "C"
U0445	Invalid Data Received From Body Control Module (BCM) "D"
U0446	Invalid Data Received From Body Control Module (BCM) "E"
U0447	Invalid Data Received From Gateway "A"
U0448	Invalid Data Received From Gateway "B"
U0449	Invalid Data Received From Gateway "C"
U044A	Invalid Data Received From Gateway "D"
U044B	ISO/SAE Reserved
U044C	ISO/SAE Reserved
U044D	ISO/SAE Reserved
U044E	ISO/SAE Reserved
U044F	ISO/SAE Reserved
U0450	ISO/SAE Reserved
U0451	Invalid Data Received From Gateway "E"
U0452	Invalid Data Received From Restraints Control Module
U0453	Invalid Data Received From Side Restraints Control Module Left
U0454	Invalid Data Received From Side Restraints Control Module
U0455	Invalid Data Received From Restraints Occupant Classification System Module
U0456	Invalid Data Received From Coolant Temperature Control Module
U0457	Invalid Data Received From Information Center "A"
U0458	Invalid Data Received From Information Center "B"
U0459	Invalid Data Received From Head Up Display
U045A	Invalid Data Received From Parking Assist Control Module "A"
U045B	ISO/SAE Reserved
U045C	ISO/SAE Reserved
U045D	ISO/SAE Reserved

Codes	Definition
U045E	ISO/SAE Reserved
U045F	ISO/SAE Reserved
U0460	ISO/SAE Reserved
U0461	Invalid Data Received From Audible Alert Control Module
U0462	Invalid Data Received From Compass Module
U0463	Invalid Data Received From Navigation Display Module
U0464	Invalid Data Received From Navigation Control Module
U0465	Invalid Data Received From PTO Control Module
U0466	Invalid Data Received From HVAC Control Module Rear
U0467	Invalid Data Received From Fuel Additive Control Module
U0468	Invalid Data Received From Fuel Cell Control Module
U0469	Invalid Data Received From Starter / Generator Control Module
U046A	Invalid Data Received From Sunroof Control Module
U046B	Invalid Data Received From Global Positioning System Module
U046C	ISO/SAE Reserved
U046D	ISO/SAE Reserved
U046E	ISO/SAE Reserved
U046F	ISO/SAE Reserved
U0470	ISO/SAE Reserved
U0471	Invalid Data Received From "Restraints System Sensor A"
U0472	Invalid Data Received From "Restraints System Sensor B"
U0473	Invalid Data Received From "Restraints System Sensor C"
U0474	Invalid Data Received From "Restraints System Sensor D"
U0475	Invalid Data Received From "Restraints System Sensor E"
U0476	Invalid Data Received From "Restraints System Sensor F"
U0477	Invalid Data Received From "Restraints System Sensor G"
U0478	Invalid Data Received From "Restraints System Sensor H"
U0479	Invalid Data Received From "Restraints System Sensor I"
U047A	Invalid Data Received From "Restraints System Sensor J"
U047B	Invalid Data Received From "Restraints System Sensor K"
U047C	Invalid Data Received From "Restraints System Sensor L"
U047D	Invalid Data Received From "Restraints System Sensor M"
U047E	Invalid Data Received From "Restraints System Sensor N"
U047F	Invalid Data Received From Seatbelt Pretensioner Module "A"
U0480	Invalid Data Received From Seatbelt Pretensioner Module "B"
U0481	Invalid Data Received From Automatic Lighting Control Module
U0482	Invalid Data Received From Headlamp Leveling Control Module
U0483	Invalid Data Received From Lighting Control Module Front
U0484	Invalid Data Received From Lighting Control Module Rear "A"
U0485	Invalid Data Received From Radio
U0486	Invalid Data Received From Antenna Control Module
U0487	Invalid Data Received From AMP Unit "A"
U0488	Invalid Data Received From Digital Disc Player/Changer Module "A"
U0489	Invalid Data Received From Digital Disc Player/Changer Module "B"

Codes	Definition
U048A	Invalid Data Received From Digital Disc Player/Changer Module "C"
U048B	ISO/SAE Reserved
U048C	ISO/SAE Reserved
U048D	ISO/SAE Reserved
U048E	ISO/SAE Reserved
U048F	ISO/SAE Reserved
U0490	ISO/SAE Reserved
U0491	Invalid Data Received From Digital Disc Player/Changer Module "D"
U0492	Invalid Data Received From Television
U0493	Invalid Data Received From Personal Computer
U0494	Invalid Data Received From "Digital Audio Control Module A"
U0495	Invalid Data Received From "Digital Audio Control Module B"
U0496	Invalid Data Received From Subscription Entertainment Receiver Module
U0497	Invalid Data Received From Entertainment Control Module Rear "A"
U0498	Invalid Data Received From Telephone Control Module
U0499	Invalid Data Received From Telematic Control Module
U049A	Invalid Data Received From "Door Control Module A"
U049B	ISO/SAE Reserved
U049C	ISO/SAE Reserved
U049D	ISO/SAE Reserved
U049E	ISO/SAE Reserved
U049F	ISO/SAE Reserved
U04A0	ISO/SAE Reserved
U04A1	ISO/SAE Reserved
U04A2	ISO/SAE Reserved
U04A3	ISO/SAE Reserved
U04A4	ISO/SAE Reserved
U04A5	ISO/SAE Reserved
U04A6	ISO/SAE Reserved
U04A7	ISO/SAE Reserved
U04A8	ISO/SAE Reserved
U04A9	ISO/SAE Reserved
U04AA	ISO/SAE Reserved
U04AB	ISO/SAE Reserved
U04AC	ISO/SAE Reserved
U04AD	ISO/SAE Reserved
U04AE	ISO/SAE Reserved
U04AF	ISO/SAE Reserved
U04B0	ISO/SAE Reserved
U04B1	ISO/SAE Reserved
U04B2	ISO/SAE Reserved
U04B3	ISO/SAE Reserved
U04B4	ISO/SAE Reserved
U04B5	ISO/SAE Reserved

Codes	Definition
U04B6	ISO/SAE Reserved
U04B7	ISO/SAE Reserved
U04B8	ISO/SAE Reserved
U04B9	ISO/SAE Reserved
U04BA	ISO/SAE Reserved
U04BB	ISO/SAE Reserved
U04BC	ISO/SAE Reserved
U04BD	ISO/SAE Reserved
U04BE	ISO/SAE Reserved
U04BF	ISO/SAE Reserved
U04C0	ISO/SAE Reserved
U04C1	ISO/SAE Reserved
U04C2	ISO/SAE Reserved
U04C3	ISO/SAE Reserved
U04C4	ISO/SAE Reserved
U04C5	ISO/SAE Reserved
U04C6	ISO/SAE Reserved
U04C7	ISO/SAE Reserved
U04C8	ISO/SAE Reserved
U04C9	ISO/SAE Reserved
U04CA	ISO/SAE Reserved
U04CB	ISO/SAE Reserved
U04CC	ISO/SAE Reserved
U04CD	ISO/SAE Reserved
U04CE	ISO/SAE Reserved
U04CF	ISO/SAE Reserved
U04D0	ISO/SAE Reserved
U04D1	ISO/SAE Reserved
U04D2	ISO/SAE Reserved
U04D3	ISO/SAE Reserved
U04D4	ISO/SAE Reserved
U04D5	ISO/SAE Reserved
U04D6	ISO/SAE Reserved
U04D7	ISO/SAE Reserved
U04D8	ISO/SAE Reserved
U04D9	ISO/SAE Reserved
U04DA	ISO/SAE Reserved
U04DB	ISO/SAE Reserved
U04DC	ISO/SAE Reserved
U04DD	ISO/SAE Reserved
U04DE	ISO/SAE Reserved
U04DF	ISO/SAE Reserved
U04E0	ISO/SAE Reserved
U04E1	ISO/SAE Reserved

Codes	Definition
U04E2	ISO/SAE Reserved
U04E3	ISO/SAE Reserved
U04E4	ISO/SAE Reserved
U04E5	ISO/SAE Reserved
U04E6	ISO/SAE Reserved
U04E7	ISO/SAE Reserved
U04E8	ISO/SAE Reserved
U04E9	ISO/SAE Reserved
U04EA	ISO/SAE Reserved
U04EB	ISO/SAE Reserved
U04EC	ISO/SAE Reserved
U04ED	ISO/SAE Reserved
U04EE	ISO/SAE Reserved
U04EF	ISO/SAE Reserved
U04F0	ISO/SAE Reserved
U04F1	ISO/SAE Reserved
U04F2	ISO/SAE Reserved
U04F3	ISO/SAE Reserved
U04F4	ISO/SAE Reserved
U04F5	ISO/SAE Reserved
U04F6	ISO/SAE Reserved
U04F7	ISO/SAE Reserved
U04F8	ISO/SAE Reserved
U04F9	ISO/SAE Reserved
U04FA	ISO/SAE Reserved
U04FB	ISO/SAE Reserved
U04FC	ISO/SAE Reserved
U04FD	ISO/SAE Reserved
U04FE	ISO/SAE Reserved
U04FF	ISO/SAE Reserved
U0500	ISO/SAE Reserved
U0501	Invalid Data Received From "Door Control Module B"
U0502	Invalid Data Received From "Door Control Module C"
U0503	Invalid Data Received From "Door Control Module D"
U0504	Invalid Data Received From "Door Control Module E"
U0505	Invalid Data Received From "Door Control Module F"
U0506	Invalid Data Received From "Door Control Module G"
U0507	Invalid Data Received From Folding Top Control Module
U0508	Invalid Data Received From Moveable Roof Control Module
U0509	Invalid Data Received From "Seat Control Module A"
U050A	Invalid Data Received From "Seat Control Module B"
U050B	ISO/SAE Reserved
U050C	ISO/SAE Reserved
U050D	ISO/SAE Reserved

Codes	Definition
U050E	ISO/SAE Reserved
U050F	ISO/SAE Reserved
U0510	ISO/SAE Reserved
U0511	Invalid Data Received From "Seat Control Module C"
U0512	Invalid Data Received From "Seat Control Module D"
U0513	Invalid Data Received From Yaw Rate Sensor Module
U0514	Invalid Data Received From Mirror Control Module
U0515	Invalid Data Received From Remote Function Actuation
U0516	Invalid Data Received From "Door Switch A"
U0517	Invalid Data Received From "Door Switch B"
U0518	Invalid Data Received From "Door Switch C"
U0519	Invalid Data Received From "Door Switch D"
U051A	Invalid Data Received From "Door Switch E"
U051B	ISO/SAE Reserved
U051C	ISO/SAE Reserved
U051D	ISO/SAE Reserved
U051E	ISO/SAE Reserved
U051F	ISO/SAE Reserved
U0520	ISO/SAE Reserved
U0521	Invalid Data Received From "Door Switch F"
U0522	Invalid Data Received From "Door Switch G"
U0523	Invalid Data Received From "Door Window Motor A"
U0524	Invalid Data Received From "Door Window Motor B"
U0525	Invalid Data Received From "Door Window Motor C"
U0526	Invalid Data Received From "Door Window Motor D"
U0527	Invalid Data Received From "Door Window Motor E"
U0528	Invalid Data Received From "Door Window Motor F"
U0529	Invalid Data Received From "Door Window Motor G"
U052A	Invalid Data Received From Heated Steering Wheel Module
U052B	ISO/SAE Reserved
U052C	ISO/SAE Reserved
U052D	ISO/SAE Reserved
U052E	ISO/SAE Reserved
U052F	ISO/SAE Reserved
U0530	ISO/SAE Reserved
U0531	Invalid Data Received From Rear Gate Module
U0532	Invalid Data Received From Rain Sensing Module
U0533	Invalid Data Received From Side Obstacle Detection Control Module Left
U0534	Invalid Data Received From Side Obstacle Detection Control Module Right
U0535	Invalid Data Received From Convenience Recall Module
U0536	Invalid Data Received From Lateral Acceleration Sensor Module
U0537	Invalid Data Received From Column Lock Module
U0538	Invalid Data Received From "Digital Audio Control Module C"
U0539	Invalid Data Received From "Digital Audio Control Module D"

Codes	Definition
U053A	Invalid Data Received From Entrapment Control Module "A"
U053B	Invalid Data Received From Image Processing Module "A"
U053C	Invalid Data Received From Image Processing Module "B"
U053D	Invalid Data Received From Image Processing Module "C"
U053E	ISO/SAE Reserved
U053F	ISO/SAE Reserved
U0540	ISO/SAE Reserved
U0541	Invalid Data Received From Entrapment Control Module "B"
U0542	Invalid Data Received From Headlamp Control Module "A"
U0543	Invalid Data Received From Headlamp Control Module "B"
U0544	Invalid Data Received From Parking Assist Control Module "B"
U0545	Invalid Data Received From Running Board Control Module
U0546	Invalid Data Received From Entertainment Control Module Front
U0547	Invalid Data Received From "Seat Control Module E"
U0548	Invalid Data Received From "Seat Control Module F"
U0549	Invalid Data Received From Remote Accessory Module
U054A	Invalid Data Received From Entertainment Control Module Rear "B"
U054B	Invalid Data Received From Interior Lighting Control Module
U054C	ISO/SAE Reserved
U054D	ISO/SAE Reserved
U054E	ISO/SAE Reserved
U054F	ISO/SAE Reserved
U0550	ISO/SAE Reserved
U0551	Invalid Data Received From Impact Classification System Module
U0552	Invalid Data Received From Running Board Control Module "B"
U0553	Invalid Data Received From Lighting Control Module Rear "B"
U0554	Invalid Data Received From Accessory Protocol Interface Module
U0555	Invalid Data Received From Remote Start Module
U0556	Invalid Data Received From Front Display Interface Module
U0557	Invalid Data Received From Front Controls Interface Module "A"
U0558	Invalid Data Received From Front Controls/Display Interface Module
U0559	Invalid Data Received From Radio Transceiver
U055A	Invalid Data Received From Special Purpose Vehicle Control Module (VCM) "A"
U055B	Invalid Data Received From Special Purpose Vehicle Control Module (VCM) "B"
U055C	Invalid Data Received From Special Purpose Vehicle Control Module (VCM) "C"
U055D	Invalid Data Received From Special Purpose Vehicle Control Module (VCM) "D"
U055E	Invalid Data Received From Front Controls Interface Module "B"
U0561	Invalid Data Received From Seat Control Switch Module "A"
U0562	Invalid Data Received From Seat Control Switch Module "B"
U0563	Invalid Data Received From AMP Unit "B"
U0564	Invalid Data Received From Speech Recognition Module

Codes	Definition
U0565	Invalid Data Received From Camera Module Rear
U0566	ISO/SAE Reserved
U0567	ISO/SAE Reserved
U0568	ISO/SAE Reserved
U0569	ISO/SAE Reserved
U056A	ISO/SAE Reserved
U056B	ISO/SAE Reserved
U056C	ISO/SAE Reserved
U056D	ISO/SAE Reserved
U056E	ISO/SAE Reserved
U056F	ISO/SAE Reserved
U0570	ISO/SAE Reserved
U0571	ISO/SAE Reserved
U0572	ISO/SAE Reserved
U0573	ISO/SAE Reserved
U0574	ISO/SAE Reserved
U0575	ISO/SAE Reserved
U0576	ISO/SAE Reserved
U0577	ISO/SAE Reserved
U0578	ISO/SAE Reserved
U0579	ISO/SAE Reserved
U057A	ISO/SAE Reserved
U057B	ISO/SAE Reserved
U057C	ISO/SAE Reserved
U057D	ISO/SAE Reserved
U057E	ISO/SAE Reserved
U057F	ISO/SAE Reserved
U0580	ISO/SAE Reserved
U0581	ISO/SAE Reserved
U0582	ISO/SAE Reserved
U0583	ISO/SAE Reserved
U0584	ISO/SAE Reserved
U0585	ISO/SAE Reserved
U0586	ISO/SAE Reserved
U0587	Invalid Data Received From With Radiator Anti Tamper Device
U0588	Invalid Data Received From Transmission Fluid Pump Module/p>
U0589	Invalid Data Received From DC to AC Converter Control Module "A"
U058A	Invalid Data Received From DC to AC Converter Control Module "B"
U058B	ISO/SAE Reserved
U058C	ISO/SAE Reserved
U058D	ISO/SAE Reserved
U058E	ISO/SAE Reserved
U058F	ISO/SAE Reserved
U0590	ISO/SAE Reserved

Codes	Definition
U0591	ISO/SAE Reserved
U0592	Invalid Data Received From Gear Shift Control Module "B"
U0593	Invalid Data Received From Drive Motor Control Module (DMCM) "B"
U0594	Invalid Data Received From Hybrid Powertrain Control Module
U0595	Invalid Data Received From Powertrain Control Monitor Module
U0596	Invalid Data Received From AC to AC Converter Control Module
U0597	Invalid Data Received From AC to DC Converter Control Module "A"
U0598	Invalid Data Received From AC to DC Converter Control Module "B"
U0599	Invalid Data Received From DC to DC Converter Control Module "A"
U059A	Invalid Data Received From DC to DC Converter Control Module "B"
U059B	Invalid Data Received From Hybrid Battery Pack Sensor Module
U059C	Invalid Data Received From Drive Motor Control Module (DMCM) "C"
U059D	Invalid Data Received From Drive Motor Control Module (DMCM) "D"
U059E	Invalid Data Received From NOX Sensor "A"
U059F	Invalid Data Received From NOX Sensor "B"
U05A0	ISO/SAE Reserved
U05A1	ISO/SAE Reserved
U05A2	ISO/SAE Reserved
U05A3	ISO/SAE Reserved
U05A4	ISO/SAE Reserved
U05A5	ISO/SAE Reserved
U05A6	ISO/SAE Reserved
U05A7	ISO/SAE Reserved
U05A8	ISO/SAE Reserved
U05A9	ISO/SAE Reserved
U05AA	ISO/SAE Reserved
U05AB	ISO/SAE Reserved
U05AC	ISO/SAE Reserved
U05AD	ISO/SAE Reserved
U05AE	ISO/SAE Reserved
U05AF	ISO/SAE Reserved
U05B0	ISO/SAE Reserved
U05B1	ISO/SAE Reserved
U05B2	ISO/SAE Reserved
U05B3	ISO/SAE Reserved
U05B4	ISO/SAE Reserved
U05B5	ISO/SAE Reserved
U05B6	ISO/SAE Reserved
U05B7	ISO/SAE Reserved
U05B8	ISO/SAE Reserved
U05B9	ISO/SAE Reserved
U05BA	ISO/SAE Reserved
U05BB	ISO/SAE Reserved
U05BC	ISO/SAE Reserved

Codes	Definition
U05BD	ISO/SAE Reserved
U05BE	ISO/SAE Reserved
U05BF	ISO/SAE Reserved
U05C0	ISO/SAE Reserved
U05C1	ISO/SAE Reserved
U05C2	ISO/SAE Reserved
U05C3	ISO/SAE Reserved
U05C4	ISO/SAE Reserved
U05C5	ISO/SAE Reserved
U05C6	ISO/SAE Reserved
U05C7	ISO/SAE Reserved
U05C8	ISO/SAE Reserved
U05C9	ISO/SAE Reserved
U05CA	ISO/SAE Reserved
U05CB	ISO/SAE Reserved
U05CC	ISO/SAE Reserved
U05CD	ISO/SAE Reserved
U05CE	ISO/SAE Reserved
U05CF	ISO/SAE Reserved
U05D0	ISO/SAE Reserved
U05D1	ISO/SAE Reserved
U05D2	ISO/SAE Reserved
U05D3	ISO/SAE Reserved
U05D4	ISO/SAE Reserved
U05D5	ISO/SAE Reserved
U05D6	ISO/SAE Reserved
U05D7	ISO/SAE Reserved
U05D8	ISO/SAE Reserved
U05D9	ISO/SAE Reserved
U05DA	ISO/SAE Reserved
U05DB	ISO/SAE Reserved
U05DC	ISO/SAE Reserved
U05DD	ISO/SAE Reserved
U05DE	ISO/SAE Reserved
U05DF	ISO/SAE Reserved
U05E0	ISO/SAE Reserved
U05E1	ISO/SAE Reserved
U05E2	ISO/SAE Reserved
U05E3	ISO/SAE Reserved
U05E4	ISO/SAE Reserved
U05E5	ISO/SAE Reserved
U05E6	ISO/SAE Reserved
U05E7	ISO/SAE Reserved
U05E8	ISO/SAE Reserved

Codes	Definition
U05E9	ISO/SAE Reserved
U05EA	ISO/SAE Reserved
U05EB	ISO/SAE Reserved
U05EC	ISO/SAE Reserved
U05ED	ISO/SAE Reserved
U05EE	ISO/SAE Reserved
U05EF	ISO/SAE Reserved
U05F0	ISO/SAE Reserved
U05F1	ISO/SAE Reserved
U05F2	ISO/SAE Reserved
U05F3	ISO/SAE Reserved
U05F4	ISO/SAE Reserved
U05F5	ISO/SAE Reserved
U05F6	ISO/SAE Reserved
U05F7	ISO/SAE Reserved
U05F8	ISO/SAE Reserved
U05F9	ISO/SAE Reserved
U05FA	ISO/SAE Reserved
U05FB	ISO/SAE Reserved
U05FC	ISO/SAE Reserved
U05FD	ISO/SAE Reserved
U05FE	ISO/SAE Reserved
U05FF	ISO/SAE Reserved
U0600	ISO/SAE Reserved
U3000	Control Module
U3001	Control Module Improper Shutdown
U3002	Vehicle Identification Number (VIN)
U3003	Battery Voltage
U3004	Accessory Power Relay
U3005	Retained Accessory Power
U3006	Control Module Input Power "A"
U3007	Control Module Input Power "B"
U3008	Control Module Ground "A"
U3009	Control Module Ground "B"
U300A	Ignition Switch
U300B	Ignition Input Accessory/On/Start
U300C	Ignition Input Off/On/Start
U300D	Ignition Input On/Start
U300E	Ignition Input On
U300F	Ignition Input Accessory
U3010	Ignition Input Start
U3011	Ignition Input Off
U3012	ISO/SAE Reserved
U3013	ISO/SAE Reserved

Codes	Definition
U3014	ISO/SAE Reserved
U3017	ISO/SAE Reserved
U3018	ISO/SAE Reserved
U3019	ISO/SAE Reserved
U301A	ISO/SAE Reserved
U301B	ISO/SAE Reserved
U301C	ISO/SAE Reserved
U301D	ISO/SAE Reserved
U301E	ISO/SAE Reserved
U301F	ISO/SAE Reserved
U3020	ISO/SAE Reserved
U3021	ISO/SAE Reserved
U3022	ISO/SAE Reserved
U3023	ISO/SAE Reserved
U3024	ISO/SAE Reserved
U3025	ISO/SAE Reserved
U3026	ISO/SAE Reserved
U3027	ISO/SAE Reserved
U3028	ISO/SAE Reserved
U3029	ISO/SAE Reserved
U302A	ISO/SAE Reserved
U302B	ISO/SAE Reserved
U302C	ISO/SAE Reserved
U302D	ISO/SAE Reserved
U302E	ISO/SAE Reserved
U302F	ISO/SAE Reserved
U3030	ISO/SAE Reserved
U3031	ISO/SAE Reserved
U3032	ISO/SAE Reserved
U3033	ISO/SAE Reserved
U3034	ISO/SAE Reserved
U3035	ISO/SAE Reserved
U3036	ISO/SAE Reserved
U3037	ISO/SAE Reserved
U3038	ISO/SAE Reserved
U3039	ISO/SAE Reserved
U303A	ISO/SAE Reserved
U303B	ISO/SAE Reserved
U303C	ISO/SAE Reserved
U303D	ISO/SAE Reserved
U303E	ISO/SAE Reserved
U303F	ISO/SAE Reserved
U3040	ISO/SAE Reserved
U3041	ISO/SAE Reserved

Codes	Definition
U3042	ISO/SAE Reserved
U3043	ISO/SAE Reserved
U3044	ISO/SAE Reserved
U3045	ISO/SAE Reserved
U3046	ISO/SAE Reserved
U3047	ISO/SAE Reserved
U3048	ISO/SAE Reserved
U3049	ISO/SAE Reserved
U304A	ISO/SAE Reserved
U304B	ISO/SAE Reserved
U304C	ISO/SAE Reserved
U304D	ISO/SAE Reserved
U304E	ISO/SAE Reserved
U304F	ISO/SAE Reserved
U3050	ISO/SAE Reserved
U3051	ISO/SAE Reserved
U3052	ISO/SAE Reserved
U3053	ISO/SAE Reserved
U3054	ISO/SAE Reserved
U3055	ISO/SAE Reserved
U3056	ISO/SAE Reserved
U3057	ISO/SAE Reserved
U3058	ISO/SAE Reserved
U3059	ISO/SAE Reserved
U305A	ISO/SAE Reserved
U305B	ISO/SAE Reserved
U305C	ISO/SAE Reserved
U305D	ISO/SAE Reserved
U305E	ISO/SAE Reserved
U305F	ISO/SAE Reserved
U3060	ISO/SAE Reserved
U3061	ISO/SAE Reserved
U3062	ISO/SAE Reserved
U3063	ISO/SAE Reserved
U3064	ISO/SAE Reserved
U3065	ISO/SAE Reserved
U3066	ISO/SAE Reserved
U3067	ISO/SAE Reserved
U3068	ISO/SAE Reserved
U3069	ISO/SAE Reserved
U306A	ISO/SAE Reserved
U306B	ISO/SAE Reserved
U306C	ISO/SAE Reserved
U306D	ISO/SAE Reserved

Codes	Definition
U306E	ISO/SAE Reserved
U306F	ISO/SAE Reserved
U3070	ISO/SAE Reserved
U3071	ISO/SAE Reserved
U3072	ISO/SAE Reserved
U3073	ISO/SAE Reserved
U3074	ISO/SAE Reserved
U3075	ISO/SAE Reserved
U3076	ISO/SAE Reserved
U3077	ISO/SAE Reserved
U3078	ISO/SAE Reserved
U3079	ISO/SAE Reserved
U307A	ISO/SAE Reserved
U307B	ISO/SAE Reserved
U307C	ISO/SAE Reserved
U307D	ISO/SAE Reserved
U307E	ISO/SAE Reserved
U307F	ISO/SAE Reserved
U3080	ISO/SAE Reserved
U3081	ISO/SAE Reserved
U3082	ISO/SAE Reserved
U3083	ISO/SAE Reserved
U3084	ISO/SAE Reserved
U3085	ISO/SAE Reserved
U3086	ISO/SAE Reserved
U3087	ISO/SAE Reserved
U3088	ISO/SAE Reserved
U3089	ISO/SAE Reserved
U308A	ISO/SAE Reserved
U308B	ISO/SAE Reserved
U308C	ISO/SAE Reserved
U308D	ISO/SAE Reserved
U308E	ISO/SAE Reserved
U308F	ISO/SAE Reserved
U3090	ISO/SAE Reserved
U3091	ISO/SAE Reserved
U3092	ISO/SAE Reserved
U3093	ISO/SAE Reserved
U3094	ISO/SAE Reserved
U3095	ISO/SAE Reserved
U3096	ISO/SAE Reserved
U3097	ISO/SAE Reserved
U3098	ISO/SAE Reserved
U3099	ISO/SAE Reserved

Codes	Definition
U309A	ISO/SAE Reserved
U309B	ISO/SAE Reserved
U309C	ISO/SAE Reserved
U309D	ISO/SAE Reserved
U309E	ISO/SAE Reserved
U309F	ISO/SAE Reserved
U30A0	ISO/SAE Reserved
U30A1	ISO/SAE Reserved
U30A2	ISO/SAE Reserved
U30A3	ISO/SAE Reserved
U30A4	ISO/SAE Reserved
U30A5	ISO/SAE Reserved
U30A6	ISO/SAE Reserved
U30A7	ISO/SAE Reserved
U30A8	ISO/SAE Reserved
U30A9	ISO/SAE Reserved
U30AA	ISO/SAE Reserved
U30AB	ISO/SAE Reserved
U30AC	ISO/SAE Reserved
U30AD	ISO/SAE Reserved
U30AE	ISO/SAE Reserved
U30AF	ISO/SAE Reserved
U30B0	ISO/SAE Reserved
U30B1	ISO/SAE Reserved
U30B2	ISO/SAE Reserved
U30B3	ISO/SAE Reserved
U30B4	ISO/SAE Reserved
U30B5	ISO/SAE Reserved
U30B6	ISO/SAE Reserved
U30B7	ISO/SAE Reserved
U30B8	ISO/SAE Reserved
U30B9	ISO/SAE Reserved
U30BA	ISO/SAE Reserved
U30BB	ISO/SAE Reserved
U30BC	ISO/SAE Reserved
U30BD	ISO/SAE Reserved
U30BE	ISO/SAE Reserved
U30BF	ISO/SAE Reserved
U30C0	ISO/SAE Reserved
U30C1	ISO/SAE Reserved
U30C2	ISO/SAE Reserved
U30C3	ISO/SAE Reserved
U30C4	ISO/SAE Reserved
U30C5	ISO/SAE Reserved

Codes	Definition
U30C6	ISO/SAE Reserved
U30C7	ISO/SAE Reserved
U30C8	ISO/SAE Reserved
U30C9	ISO/SAE Reserved
U30CA	ISO/SAE Reserved
U30CB	ISO/SAE Reserved
U30CC	ISO/SAE Reserved
U30CD	ISO/SAE Reserved
U30CE	ISO/SAE Reserved
U30CF	ISO/SAE Reserved
U30D0	ISO/SAE Reserved
U30D1	ISO/SAE Reserved
U30D2	ISO/SAE Reserved
U30D3	ISO/SAE Reserved
U30D4	ISO/SAE Reserved
U30D5	ISO/SAE Reserved
U30D6	ISO/SAE Reserved
U30D7	ISO/SAE Reserved
U30D8	ISO/SAE Reserved
U30D9	ISO/SAE Reserved
U30DA	ISO/SAE Reserved
U30DB	ISO/SAE Reserved
U30DC	ISO/SAE Reserved
U30DD	ISO/SAE Reserved
U30DE	ISO/SAE Reserved
U30DF	ISO/SAE Reserved
U30E0	ISO/SAE Reserved
U30E1	ISO/SAE Reserved
U30E2	ISO/SAE Reserved
U30E3	ISO/SAE Reserved
U30E4	ISO/SAE Reserved
U30E5	ISO/SAE Reserved
U30E6	ISO/SAE Reserved
U30E7	ISO/SAE Reserved
U30E8	ISO/SAE Reserved
U30E9	ISO/SAE Reserved
U30EA	ISO/SAE Reserved
U30EB	ISO/SAE Reserved
U30EC	ISO/SAE Reserved
U30ED	ISO/SAE Reserved
U30EE	ISO/SAE Reserved
U30EF	ISO/SAE Reserved
U30F0	ISO/SAE Reserved
U30F1	ISO/SAE Reserved

Codes	Definition
U30F2	ISO/SAE Reserved
U30F3	ISO/SAE Reserved
U30F4	ISO/SAE Reserved
U30F5	ISO/SAE Reserved
U30F6	ISO/SAE Reserved
U30F7	ISO/SAE Reserved
U30F8	ISO/SAE Reserved
U30F9	ISO/SAE Reserved
U30FA	ISO/SAE Reserved
U30FB	ISO/SAE Reserved
U30FC	ISO/SAE Reserved
U30FD	ISO/SAE Reserved
U30FE	ISO/SAE Reserved
U30FF	ISO/SAE Reserved
U3100	ISO/SAE Reserved