



NISSAN MANUFACTURER-SPECIFIC TROUBLE CODES

Compiled by ***OBDCodeX***



www.obdcodex.com

Codes	Definition
Mercedes-Benz P1400	EGR Switchover Valve
Nissan B1017	SRS Occupant System Malfunction
Nissan B1018	SRS Left Occupant System Malfunction
Nissan B1019	Left Occupant Classification System (OCS) Malfunction
Nissan B1020	SRS Occupant System Malfunction
Nissan B1021	SRS Occupant System Malfunction
Nissan B1022	SRS Occupant System Malfunction
Nissan B1023	SRS Passenger A/B Indicator Circuit
Nissan B1033	Crash Zone Sensor
Nissan B1034	Crash Zone Sensor
Nissan B1035	Crash Zone Sensor
Nissan B1049	SRS Driver Airbag Module
Nissan B1050	SRS Driver Airbag Module
Nissan B1051	SRS Driver Airbag Module
Nissan B1052	SRS Driver Airbag Module
Nissan B1054	SRS Driver Airbag Module
Nissan B1055	SRS Driver Airbag Module
Nissan B1056	SRS Driver Airbag Module
Nissan B1057	SRS Driver Airbag Module
Nissan B1065	SRS Passenger Airbag Assist A/B Module Circuit
Nissan B1066	SRS Passenger Airbag Assist A/B Module Circuit
Nissan B1067	SRS Passenger Airbag Assist A/B Module Circuit
Nissan B1068	SRS Passenger Airbag Assist A/B Module Circuit
Nissan B1070	SRS Passenger Airbag Assist A/B Module Circuit
Nissan B1071	SRS Passenger Airbag Assist A/B Module Circuit
Nissan B1072	SRS Passenger Airbag Assist A/B Module Circuit
Nissan B1073	SRS Passenger Airbag Assist A/B Module Circuit
Nissan B1081	RF Seat Belt Pre-Tensioner Circuit
Nissan B1082	RF Seat Belt Pre-Tensioner
Nissan B1083	RF Seat Belt Pre-Tensioner Circuit
Nissan B1084	RF Seat Belt Pre-Tensioner Circuit
Nissan B1086	LF Seat Belt Pre-Tensioner Circuit
Nissan B1087	LF Seat Belt Pre-Tensioner Circuit
Nissan B1088	LF Seat Belt Pre-Tensioner Circuit
Nissan B1089	LF Seat Belt Pre-Tensioner Circuit
Nissan B1113	SRS Right Airbag (Satellite) Sensor
Nissan B1114	SRS Right Airbag (Satellite) Sensor
Nissan B1115	SRS Right Airbag (Satellite) Sensor Communication
Nissan B1118	SRS Left Airbag (Satellite) Sensor
Nissan B1119	SRS Left Airbag (Satellite) Sensor
Nissan B1120	SRS Left Airbag (Satellite) Sensor
Nissan B1129	SRS RF Side Airbag Module Circuit
Nissan B1130	SRS RF Side Airbag Module Circuit
Nissan B1131	SRS RF Side Airbag Module Circuit

Codes	Definition
Nissan B1132	SRS RF Side Airbag Module
Nissan B1134	SRS Left Front Side Airbag Module
Nissan B1135	SRS LF Side Airbag Module
Nissan B1136	SRS LF Side Airbag Module
Nissan B1137	LF Side Airbag Module
Nissan B1145	Right Curtain Airbag Circuit
Nissan B1146	Right Curtain Airbag Circuit
Nissan B1147	Right Curtain Airbag Circuit
Nissan B1148	Right Curtain Airbag Module Circuit
Nissan B1150	SRS Left Side Curtain Airbag Module Circuit
Nissan B1151	SRS Left Side Curtain Airbag Module Circuit
Nissan B1152	SRS Left Curtain Airbag Module Circuit
Nissan B1153	SRS Left Curtain Airbag Module Circuit
Nissan B1177	RF Seat Belt Pre-Tensioner Circuit Open
Nissan B1178	RF Seat Belt Pre-Tensioner Circuit Short
Nissan B1179	RF Seat Belt Pre-Tensioner Circuit Short
Nissan B1180	RF Seat Belt Pre-Tensioner Circuits Shorted
Nissan B1193	RF Curtain Airbag Module Circuit Open
Nissan B1194	RF Curtain Airbag Module Circuit Short
Nissan B1195	RF Curtain Airbag Module Circuit Short
Nissan B1196	LF Curtain Airbag Module Circuits Shorted
Nissan B1198	LF Curtain Airbag Module Circuit Open
Nissan B1199	LF Curtain Airbag Module Circuit Short
Nissan B1200	LF Curtain Airbag Module Circuit Short
Nissan B1201	LF Curtain Airbag Module Circuits Shorted
Nissan B1209	SRS Components Deployed - Frontal Collision
Nissan B1210	SRS Side and/or Curtain Airbag(s) Deployed
Nissan B1211	Rollover Detection
Nissan B2013	DTC Detection Logic: ID Discord IMM-STRG or I-KEY-STRG
Nissan B2014	DTC Detection Logic (Steering): Chain of STRG-IMMU
Nissan B2098	DTC Detection Logic (Ignition Relay On)
Nissan B2099	DTC Detection Logic (Ignition Relay Off)
Nissan B2108	DTC Detection Logic (Steering Lock Relay On)
Nissan B2109	DTC Detection Logic (Steering Lock Relay Off)
Nissan B210A	DTC Detection Logic (Steering Lock State)
Nissan B210B	DTC Detection Logic (Starter Control Relay On)
Nissan B210C	DTC Detection Logic (Starter Control Relay Off)
Nissan B210D	DTC Detection Logic (Starter Relay On)
Nissan B210E	DTC Detection Logic (Starter Relay Off)
Nissan B210F	DTC Detection Logic (Interlock/PNP Switch On)
Nissan B2110	DTC Detection Logic (Interlock/PNP Switch)
Nissan B2190	DTC Detection Logic (Anti-Theft Antenna Amp)
Nissan B2191	DTC Detection Logic (Detection of Key)

Codes	Definition
Nissan B2192	DTC Detection Logic (ID Discord, IMMU-ECM)
Nissan B2193	DTC Detection Logic (Chain of ECM-IMMU)
Nissan B2194	ID Discord - IMMU-I-KEY
Nissan B2195	DTC Detection Logic (Chain of ECM-IMMU)
Nissan B2205	Vehicle Speed Circuit
Nissan B2552	Intelligent Key Unit
Nissan B2553	Ignition Relay
Nissan B2555	DTC Detection Logic (Stop Lamp)
Nissan B2556	PUSH-BUTTON IGNITION SWITCH
Nissan B2557	VEHICLE SPEED
Nissan B2560	DTC Detection Logic (Starter Control Relay)
Nissan B2562	Low Voltage
Nissan B2563	BCM High Voltage
Nissan B2578	A/C In-Car Sensor Circuit
Nissan B2579	In-Car Sensor Circuit
Nissan B257B	Ambient Temperature Sensor Circuit
Nissan B257C	Ambient Temperature Sensor Circuit
Nissan B2581	A/C Evaporator Temperature Sensor
Nissan B2582	A/C Evaporator Temperature Sensor
Nissan B2590	ID Discord - BCM-I-KEY
Nissan B2601	Shift Position
Nissan B2602	Shift Position
Nissan B2603	Shift Position Status
Nissan B2604	Transmission Range, Shift Position or PNP Switch
Nissan B2605	Transmission Range, Shift Position or PNP Switch
Nissan B2606	Steering Lock Relay
Nissan B2607	Steering Lock Relay
Nissan B2608	Starter Relay
Nissan B2609	Steering Status
Nissan B260A	Ignition Relay
Nissan B260B	Steering Lock Unit
Nissan B260C	Steering Lock Unit
Nissan B260D	Steering Lock Unit
Nissan B260F	Interruption of Engine Status Signal
Nissan B2612	Steering Status
Nissan B2617	Starter Relay Circuit
Nissan B2619	BCM
Nissan B261A	Push-Button Ignition Switch
Nissan B261E	Vehicle Type
Nissan B2621	Inside Antenna
Nissan B2622	Inside Antenna 2 Circuit
Nissan B2623	Inside Key Antenna 3
Nissan B2630	Sunload Sensor
Nissan B2631	Sunload Sensor

Codes	Definition
Nissan B2632	A/C Air Mix Door Actuator
Nissan B2633	A/C Air Mix Door Actuator
Nissan B2634	A/C Air Mix Door Actuator (Passenger)
Nissan B2635	A/C Air Mix Door Actuator (Passenger)
Nissan B2636	A/C Mode Door Actuator
Nissan B2637	A/C Bi-Level Door Failure
Nissan B2638	Defrost/Foot Door 1 Failure
Nissan B2639	Defrost Door Failure
Nissan B263D	Fresh Air Intake Door Failure
Nissan B263E	20% Fresh Air Intake Door Failure
Nissan B263F	Recirc Air Door Failure
Nissan B2640	Electric Compressor (Hybrid)
Nissan B2641	Electric Compressor (Hybrid)
Nissan B2642	Electric Compressor (Hybrid)
Nissan B2643	Electric Compressor (Hybrid)
Nissan B2644	Electric Compressor (Hybrid)
Nissan B2645	Electric Compressor (Hybrid)
Nissan B2646	Electric Compressor (Hybrid)
Nissan B2647	Electric Compressor (Hybrid)
Nissan B2648	Electric Compressor (Hybrid)
Nissan B2649	Electric Compressor (Hybrid)
Nissan B264A	Electric Compressor (Hybrid)
Nissan B264C	Electric Compressor (Hybrid)
Nissan B264D	Electric Compressor (Hybrid)
Nissan B264E	Electric Compressor (Hybrid)
Nissan B264F	Electric Compressore (Hybrid)
Nissan B2651	Electric Compressor (Hybrid)
Nissan B2652	Electric Compressor (Hybrid)
Nissan B2653	Electric Compressor (Hybrid)
Nissan B2654	Defrost/Foot Door 2 Failure
Nissan B2655	Bi-Level Door 2 Failure
Nissan B2656	A/C Fresh Air Door Failure
Nissan B26E8	Clutch Interlock Switch
Nissan B26E9	Steering Status
Nissan B26EA	Key Registration
Nissan B2700	Front Sonar Sensor
Nissan B2701	Front Sonar Sensor Circuit
Nissan B2702	Front Sonar Sensor
Nissan B2703	Front Sonar Sensor Circuit
Nissan B2704	Rear Sonar Sensor
Nissan B2705	Rear Sonar Sensor Circuit
Nissan B2706	Rear Sonar Sensor
Nissan B2707	Rear Sonar Sensor Circuit
Nissan B2708	Rear Inner Sonar Sensor

Codes	Definition
Nissan B2709	Rear Inner Sonar Sensor Circuit
Nissan B270A	Rear Inner Sonar Sensor
Nissan B270B	Rear Inner Sonar Sensor Circuit
Nissan B270C	Front Inner Sonar Sensor
Nissan B270D	Front Inner Sonar Sensor Circuit
Nissan B270E	Front Inner Sonar Sensor
Nissan B270F	Front Inner Sonar Sensor Circuit
Nissan B2878	A/C In-Car Sensor Out of Range (Low)
Nissan C1101	ABS RR Wheel Speed Sensor 1
Nissan C1102	ABS LR Wheel Speed Sensor 1
Nissan C1103	ABS RF Wheel Speed Sensor 1
Nissan C1104	ABS LF Wheel Speed Sensor 1
Nissan C1105	ABS RR Wheel Speed Sensor 2
Nissan C1106	ABS LR Wheel Speed Sensor 2
Nissan C1107	ABS RF Wheel Speed Sensor 2
Nissan C1108	ABS LF Wheel Speed Sensor 2
Nissan C1109	Battery Voltage [Abnormal]
Nissan C1110	ABS Controller and Electric Unit (Control Unit)
Nissan C1111	ABS Pump Motor
Nissan C1113	Longitudinal G Sensor
Nissan C1115	ABS Wheel Speed Sensor Signal Abnormal
Nissan C1116	Stop Lamp Switch
Nissan C1120	LF In ABS Solenoid
Nissan C1121	LF Out ABS Solenoid
Nissan C1122	RF In ABS Solenoid
Nissan C1123	RF Out ABS Solenoid
Nissan C1124	LR In ABS Solenoid
Nissan C1125	LR Out ABS Solenoid
Nissan C1126	RR In ABS Solenoid
Nissan C1127	RR Out ABS Solenoid
Nissan C1130	Engine Signal 1
Nissan C1131	Engine Signal 2
Nissan C1132	Engine Signal 3
Nissan C1133	Engine Signal 4
Nissan C1134	Engine Signal 5
Nissan C1136	Engine Signal 6
Nissan C1140	ABS Actuator Relay System
Nissan C1142	ABS Pressure Sensor Circuit
Nissan C1143	Steering Angle Sensor
Nissan C1144	Steering Angle Sensor Incomplete Adjustment
Nissan C1145	Yaw Rate Sensor
Nissan C1146	Yaw Side G Sensor Circuit
Nissan C1155	Brake Fluid Low
Nissan C1156	Steering Angle Sensor CAN Communication

Codes	Definition
Nissan C1160	ABS Decel G Sensor Set
Nissan C1163	Steering Angle Sensor Safe Mode
Nissan C1164	ABS Cut Valve 1
Nissan C1165	ABS Cut Valve 2
Nissan C1166	ABS Suction Valve 1 System
Nissan C1167	ABS Suction Valve 2 System
Nissan C1170	Variant Coding
Nissan C1176	Stop Lamp Switch 2
Nissan C1178	ABS Active Booster
Nissan C1179	ABS Delta S Sensor
Nissan C1181	ABS Active Booster
Nissan C1184	ABS Active Booster
Nissan C1189	ABS Active Boostere
Nissan C11A0	Yaw Rate Sensor Calibration
Nissan C1231	Steering Angle Sensor Circuit
Nissan C1232	G Sensor Stuck 2
Nissan C1234	Yaw Rate Sensor
Nissan C1243	G Sensor
Nissan C1244	G Sensor Circuit
Nissan C1245	G Sensor Output
Nissan C1271	RF Speed Output
Nissan C1272	LF Speed Output
Nissan C1273	RR Wheel Speed Output
Nissan C1274	LR Wheel Speed Output
Nissan C1275	RF Wheel Speed Output High
Nissan C1276	LF Wheel Speed Output High
Nissan C1277	RR Wheel Speed Output High
Nissan C1278	LR Wheel Speed Output High
Nissan C1279	Acceleration Sensor Output Voltage Malfunction
Nissan C1290	Steering Angle Set Point
Nissan C1300	ABS ECU
Nissan C1310	ABS HV System
Nissan C1311	ABS Main Relay 1 Open
Nissan C1312	ABS Main Relay 1 Short
Nissan C1313	ABS Main Relay 2 Open
Nissan C1314	ABS Main Relay 2 Short
Nissan C1336	G Sensor Calibration
Nissan C1345	Brake Linear Valve Calibration
Nissan C1346	ABS Stroke Sensor Calibration
Nissan C1368	Brake Linear Standard Value
Nissan C1381	Yaw Rate/G Sensor Power
Nissan C1392	ABS Stroke Sensor Set
Nissan C1601	Battery Power Supply (Hybrid)
Nissan C1604	EPS Torque Sensor

Codes	Definition
Nissan C1606	EPS Motor
Nissan C1607	Steering EPS EEPROM
Nissan C1608	Steering EPS Control Unit
Nissan C1609	Vehicle Speed Signal
Nissan C1613	EPS Torque Sensor Calibration
Nissan C16A0	Hybrid Vehicle Control ECU
Nissan C16A1	EPS DC/DC Converter
Nissan C16A2	EPS Motor Angle Sensor Initialization
Nissan C1704	LF Low Pressure Signal
Nissan C1705	RF Low Pressure Signal
Nissan C1706	RR Low Pressure Signal
Nissan C1707	LR Low Pressure Signal
Nissan C1708	Data From LF Transmitter Cannot Be Received.
Nissan C1709	Data From RF Transmitter Cannot Be Received.
Nissan C1710	Data From RR Transmitter Cannot Be Received.
Nissan C1711	Data From LR Transmitter Cannot Be Received.
Nissan C1712	Checksum Data From LF Transmitter is Malfunctioning
Nissan C1713	Checksum Data from RF Transmitter is Malfunctioning.
Nissan C1714	Checksum Data from RR Transmitter is Malfunctioning.
Nissan C1715	Checksum Data from LR Transmitter is Malfunctioning.
Nissan C1716	Air Pressure Data from LF Transmitter is Malfunctioning.
Nissan C1717	Air Pressure Data from RF Transmitter is Malfunctioning.
Nissan C1718	Air Pressure Data from RR Transmitter is Malfunctioning.
Nissan C1719	Air Pressure Data from LR Transmitter is Malfunctioning.
Nissan C1720	Function Code Data from LF Transmitter is Malfunctioning.
Nissan C1721	Function Code Data from RF Transmitter is Malfunctioning.
Nissan C1722	Function Code Data from RR Transmitter is Malfunctioning.
Nissan C1723	Function Code Data from LR Transmitter is Malfunctioning.
Nissan C1724	Battery Voltage of LF Transmitter Drops.
Nissan C1725	Battery Voltage of RF Transmitter Drops.
Nissan C1726	Battery Voltage of RR Transmitter Drops.
Nissan C1727	Battery Voltage of LR Transmitter Drops.
Nissan C1729	Vehicle Speed Signal is in Error
Nissan C1730	TPMS Malfunction in BCM.
Nissan C1735	Ignition Signal
Nissan C1801	Vehicle Height Sensor
Nissan C1802	Suspension Compressor Relay
Nissan C1803	Suspension Compressor Exhaust Solenoid
Nissan C1804	Suspension Height Adjusting Malfunction
Nissan C1805	Suspension Height Adjusting Malfunction
Nissan C1806	Suspension Height Sensor Locking Malfunction
Nissan C1807	Suspension Height Sensor 5V Malfunction
Nissan C1808	Suspension Compressor - Integral Time Malfunction Supplying Air

Codes	Definition
Nissan P101D	A/F Sensor Heater Circuit Performance Bank 1 Sensor 1 Stuck ON
Nissan P102D	O2 Sensor Heater Circuit Performance Bank 1 Sensor 2 Stuck ON
Nissan P1065	PCM Backup Circuit Malfunction
Nissan P106A	Evaporative Emission System Pressure Sensor - Manifold Absolute Pressure Correlation
Nissan P1102	Mass Airflow Sensor Signal Range/Performance
Nissan P1105	MAP/BARO Switch Solenoid Valve
Nissan P1108	Manifold Absolute Pressure Sensor Circuit Malfunction
Nissan P1110	Intake Valve Timing Control Performance
Nissan P1111	Intake Valve Timing Control Circuit Malfunction
Nissan P1121	Electronic Throttle Control Actuator Malfunction
Nissan P1122	Electronic Throttle Control Actuator Malfunction
Nissan P1124	Electronic Throttle Control Actuator Relay High Input
Nissan P1126	Thermostat Malfunction (Stuck Open)
Nissan P1128	Electronic Throttle Control Actuator Motor Circuit Malfunction
Nissan P1130	Swirl Control Solenoid Valve System Malfunction
Nissan P1131	Swirl Control Solenoid Valve Circuit Malfunction
Nissan P1132	Swirl Control Valve Circuit Malfunction
Nissan P1135	Intake Valve Timing Control System Malfunction (Bank 2)
Nissan P1136	Intake Valve Timing Control Circuit Malfunction (Bank 2)
Nissan P1137	Swirl Control Valve Control Position Sensor Circuit Malfunction
Nissan P1138	Swirl Control Valve Control Performance
Nissan P1140	Intake Valve Timing Control Position Sensor Circuit (Bank 1)
Nissan P1143	HO2S-11 (Bank 1 Sensor 1) Lean Shift Monitoring (Bank 1)
Nissan P1144	HO2S-11 (Bank 1 Sensor 1) Rich Shift Monitoring (Bank 1)
Nissan P1145	Intake Valve Timing Control Position Sensor Circuit (Bank 2)
Nissan P1146	HO2S-12 (Bank 1 Sensor 2) Lean Shift Monitoring (Bank 1)
Nissan P1147	HO2S-12 (Bank 1 Sensor 2) Rich Shift Monitoring (Bank 1)
Nissan P1148	Closed Loop Control Function (Includes Hybrid Models)
Nissan P1163	HO2S-21 (Bank 2 Sensor 1) Lean Shift Monitoring (Bank 2)
Nissan P1164	HO2S-21 (Bank 2 Sensor 1) Rich Shift Monitoring (Bank 2)
Nissan P1166	HO2S-22 (Bank 2 Sensor 2) Lean Shift Monitoring (Bank 2)
Nissan P1167	HO2S-22 (Bank 2 Sensor 2) Rich Shift Monitoring (Bank 2)
Nissan P1168	Closed Loop Control Function (Bank 2)
Nissan P1186	LF Seat Belt Pre-Tensioner Circuit Open
Nissan P1187	LF Seat Belt Pre-Tensioner Circuit Short
Nissan P1188	LF Seat Belt Pre-Tensioner Circuit Short
Nissan P1189	LF Seat Belt Pre-Tensioner Circuit Short
Nissan P1195	Engine Does Not Start (Hybrid)

Codes	Definition
Nissan P1196	Engine Lacks Power (Hybrid)
Nissan P1197	Fuel Run Out (Hybrid)
Nissan P1211	TCS Control Unit
Nissan P1212	TCS Communication Line
Nissan P1217	Engine Over Temperature (Overheat) (Includes Hybrid Models)
Nissan P1220	Fuel Pump Control Module (FPCM)
Nissan P1225	Closed Throttle Position Learning Performance (Includes Hybrid Models)
Nissan P1226	Closed Throttle Position Learning Performance (Includes Hybrid Models)
Nissan P1227	Accelerator Pedal Position Sensor Circuit Low Input
Nissan P1228	Accelerator Pedal Position Sensor Circuit High Input
Nissan P1229	Accelerator Pedal Position Sensor 2 Power Circuit Short
Nissan P1271	A/F Sensor-11 (Bank 1 Sensor 1) Circuit Malfunction
Nissan P1272	Air Fuel Sensor (Bank 1 Sensor 1) High Input
Nissan P1273	Air Fuel Sensor (Bank 1 Sensor 1) Circuit Lean Shift
Nissan P1274	Air Fuel Sensor (Bank 1 Sensor 1) Circuit Rich Shift
Nissan P1275	Air Fuel Sensor (Bank 1 Sensor 1) Slow Response
Nissan P1276	Air Fuel Sensor (B1 S1) Lack Of Activity Detected
Nissan P1277	Air Fuel Sensor (Bank 1 Sensor 1) Heater Circuit Malfunction
Nissan P1320	Ignition Control Signal Circuit Malfunction
Nissan P1335	Crankshaft Position Reference Sensor Circuit Malfunction
Nissan P1336	Crankshaft Position Sensor Circuit Malfunction
Nissan P1400	EGR/EVAP Control Solenoid Circuit Malfunction
Nissan P1401	EGR Temperature Sensor Circuit Malfunction
Nissan P1402	EGR System Malfunction Detected (Open)
Nissan P1421	Cold Start Emission Reduction Strategy Monitoring (Includes Hybrid Models)
Nissan P1440	EVAP Canister System Small Leak (0.040) Detected
Nissan P1441	Vacuum Cut Valve Bypass Valve Circuit Malfunction
Nissan P1442	EVAP System Small Leak (0.040") Detected
Nissan P1443	Canister Control Vacuum Switch Circuit Malfunction
Nissan P1444	Canister Purge Volume Control Valve Circuit Malfunction
Nissan P1445	EVAP Canister Purge Volume Control Valve Malfunction
Nissan P1446	EVAP Canister Vent Valve Malfunction (Closed)
Nissan P1447	EVAP Control System Purge Flow Malfunction
Nissan P1448	EVAP Canister Vent Control Valve Malfunction (Open)
Nissan P1456	EVAP System Very Small Leak (0.020") Detected
Nissan P1464	Fuel Level Sensor Circuit High Input
Nissan P1490	EVAP Vacuum Cut Valve Bypass Valve Circuit Malfunction
Nissan P1491	EVAP Vacuum Cut Valve/Bypass Circuit
Nissan P1492	EVAP Canister Purge Control Solenoid Circuit Malfunction
Nissan P1493	EVAP Canister Purge Control Solenoid Performance (Open)

Codes	Definition
Nissan P1550	Battery Current Sensor Circuit Range/Performance
Nissan P1551	Battery Current Sensor Circuit Low Input
Nissan P1552	Battery Current Sensor Circuit High Input
Nissan P1553	Battery Current Sensor Performance
Nissan P1554	Battery Current Sensor Performance
Nissan P1564	ASCD Steering Switch Malfunction (Includes Hybrid Models)
Nissan P1568	ASCD Command Valve Circuit Malfunction
Nissan P1571	Radar Sensor Malfunction
Nissan P1572	Improper Aiming of Radar Sensor Beam Axis
Nissan P1574	ASCD Vehicle Speed Sensor Malfunction (Includes Hybrid Models)
Nissan P1575	Warning Buzzer Malfunction
Nissan P1578	Brake System Malfunction
Nissan P1605	A/T Diagnosis Communication Line Malfunction
Nissan P1610	NATS Antenna Amp. or Lock Mode
Nissan P1611	ID Discord -- IMMU-ECM
Nissan P1612	Chain of ECM-IMMU
Nissan P1613	NATS ECM INT CIRC-IMMU:
Nissan P1614	Chain of IMMU-ECM
Nissan P1615	Difference of Key
Nissan P1616	Communication Error from ECM to Distance Control ECU
Nissan P1617	Distance Control ECU Malfunction
Nissan P1630	Communication Error from VSC to ECM
Nissan P1631	Communication Error from ECM to VSC
Nissan P1701	Transmission Control Module (Power Supply)
Nissan P1705	Throttle Position/Accelerator Pedal Position Sensor Circuit
Nissan P1706	Park Neutral Position Switch Circuit Malfunction
Nissan P1710	A/T Fluid Temperature Sensor Circuit
Nissan P1715	Input Speed Sensor (Primary Speed Sensor/TCM Output)
Nissan P1716	A/T Turbine Revolution Sensor Circuit Malfunction:
Nissan P1720	A/T (TCM) Vehicle Speed Sensor Circuit Malfunction
Nissan P1721	Vehicle Speed Signal
Nissan P1722	Vehicle Speed Signal Circuit
Nissan P1723	CVT Speed Sensor Circuit
Nissan P1726	Throttle Control Signal Circuit
Nissan P1730	A/T Interlock
Nissan P1731	A/T 1st Engine Braking
Nissan P1740	Lock-Up Select Solenoid Valve
Nissan P1745	Line Pressure Control
Nissan P1752	Input Clutch Solenoid Valve
Nissan P1754	A/T I/C Solenoid Valve Circuit Malfunction:
Nissan P1757	Front Brake Solenoid Valve
Nissan P1759	A/T FR/B Solenoid Valve Performance:

Codes	Definition
Nissan P1760	A/T Overrun Clutch Solenoid Valve Circuit Malfunction
Nissan P1762	Direct Clutch Solenoid Valve
Nissan P1764	A/T D/C Solenoid Valve Circuit Malfunction
Nissan P1767	High & Low Reverse Clutch Solenoid Valve
Nissan P1769	A/T HLR/C Solenoid Valve Circuit Malfunction:
Nissan P1772	Low Coast Brake Solenoid Valve
Nissan P1774	Low Coast Brake Solenoid Valve Function
Nissan P1775	A/T Torque Converter Clutch Solenoid Circuit Low Input
Nissan P1776	A/T Torque Converter Clutch Solenoid Circuit High Input
Nissan P1777	Step Motor Circuit
Nissan P1778	Step Motor Circuit Malfunction
Nissan P1800	VIAS Control Solenoid Valve Circuit Malfunction
Nissan P1805	Brake Switch Signal Malfunction (Includes Hybrid Models)
Nissan P1900	Cooling Fan Control Circuit Malfunction
Nissan P3004	Power Cable Malfunction
Nissan P3190	Poor Engine Power
Nissan P3191	Engine Does Not Start
Nissan P3193	Fuel Run Out
Nissan U1000	CAN Communication Line
Nissan U1001	CAN Communication Line (Includes Hybrid models)
Nissan U1010	Control Unit (CAN) - BCM
Nissan U1020	Lost Communication with Hybrid Vehicle (HV) Control System (Hybrid)
Nissan U1021	Invalid Data Received from Hybrid Vehicle Control ECU (Hybrid)
Nissan U1022	Lost Communication with Brake ECU
Nissan U1023	Invalid Data Received from Brake ECU
Nissan U1200	AV Control Unit
Nissan U1201	AV Control Unit
Nissan U1202	AV Control Unit
Nissan U1204	GPS Comm
Nissan U1205	GPS ROM
Nissan U1206	GPS RAM
Nissan U1207	GPS RTC
Nissan U1216	AV Control Unit
Nissan U1217	AV Control Unit (Bluetooth Module)
Nissan U1218	AV Control Unit - HDD Connection
Nissan U1219	AV Control Module - HDD Read
Nissan U121A	AV Control Unit (HDD Write)
Nissan U121B	AV Control Unit (HDD Comm)
Nissan U121C	AV Control Unit (HDD Access)
Nissan U121D	AV Control Unit (DSP Connection)
Nissan U121E	AV Control Unit
Nissan U121F	AV Control Unit

Codes	Definition
Nissan U1220	AV Control Unit - XM
Nissan U1225	AV Control Unit (USB Controller)
Nissan U1227	AV Control Unit (DVD Comm)
Nissan U1228	AV Control Unit (Sub CPU Conn)
Nissan U1229	AV Control Unit (iPod Certification)
Nissan U122A	AV Control Unit (Config Unfinish)
Nissan U122E	AV Control Unit (Built-in Audio Conn)
Nissan U1240	AV Switch Connection
Nissan U1243	Display Unit
Nissan U1244	GPS Antenna
Nissan U1250	Camera Control Unit
Nissan U1255	Satellite Radio Tuner
Nissan U1258	Satellite Radio Antenna
Nissan U1263	USB
Nissan U1300	AV Communication Circuit
Nissan U1310	AV Control Unit